

Product: John Deere 1200 Hydro Bunker and Field Rake Service Repair Technical Manual

Full Download: [https://www.bobmanualstore.com/downloads/john-deere-1200-hydro](https://www.bobmanualstore.com/downloads/john-deere-1200-hydro-bunker-and-field-rake-service-repair-technical-manual/)

[ro-bunker-and-field-rake-service-repair-technical-manual/](https://www.bobmanualstore.com/downloads/john-deere-1200-hydro-bunker-and-field-rake-service-repair-technical-manual/)

JOHN DEERE
WORLDWIDE COMMERCIAL & CONSUMER
EQUIPMENT DIVISION

Bunker and Field Rake
1200 Hydro

TM2193 DEC05

TECHNICAL MANUAL



JOHN DEERE

North American Version
Litho in U.S.A.

Sample manual. Download All 150 pages at:

<https://www.bobmanualstore.com/downloads/john-deere-1200-hydro-bunker-and-field-rake-service-repair-technical-manual/>

Product: John Deere 1200 Hydro Bunker and Field Rake Service Repair Technical Manual

Full Download: <https://www.bobmanualstore.com/downloads/john-deere-1200-hyd>

[ro-bunker-and-field-rake-service-repair-technical-manual/](https://www.bobmanualstore.com/downloads/john-deere-1200-hyd-ro-bunker-and-field-rake-service-repair-technical-manual/)

Sample manual. Download All 150 pages at:

<https://www.bobmanualstore.com/downloads/john-deere-1200-hydro-bunker-and-field-rake-service-repair-technical-manual/>

INTRODUCTION

Manual Description

This technical manual is written for an experienced technician and contains sections that are specifically for this product. It is a part of a total product support program.

The manual is organized so that all the information on a particular system is kept together. The order of grouping is as follows:

- Table of Contents
- Specifications and Information
- Identification Numbers
- Tools and Materials
- Component Location
- Schematics and Harnesses
- Theory of Operation
- Operation and Diagnostics
- Diagnostics
- Tests and Adjustments
- Repair
- Other

NOTE: Depending on the particular section or system being covered, not all of the above groups may be used.

The bleed tabs for the pages of each section will align with the sections listed on this page. Page numbering is consecutive from the beginning of the Safety section through the last section.

We appreciate your input on this manual. If you find any errors or want to comment on the layout of the manual please contact us.

Safety

Specifications and Information

Engine

Electrical

Hydraulics

Steering

Brakes

Attachments

Miscellaneous

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 2005
Deere & Co.
John Deere Worldwide Commercial and
Consumer Equipment Division
All rights reserved
Previous Editions
COPYRIGHT© 2004

SAFETY

Recognize Safety Information



MIF

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.


Follow recommended precautions and safe servicing practices.

Understand Signal Words

A signal word - DANGER, WARNING, or CAUTION - is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.

Replace Safety Signs




MIF

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.

Handle Fluids Safely - Avoid Fires

Be Prepared For Emergencies




MIF

- When you work around fuel, do not smoke or work near heaters or other fire hazards.
- Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.
- Make sure machine is clean of trash, grease, and debris.
- Do not store oily rags; they can ignite and burn spontaneously.
- Be prepared if a fire starts.
- Keep a first aid kit and fire extinguisher handy.
- Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.

SAFETY

Use Care In Handling and Servicing Batteries



MIF

Prevent Battery Explosions

- Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.
- Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.
- Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).

Prevent Acid Burns

- Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid acid burns by:

1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.


If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 10 - 15 minutes.
4. Get medical attention immediately.

If acid is swallowed:

1. Drink large amounts of water or milk.
2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
3. Get medical attention immediately.

Wear Protective Clothing



MIF

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.

Use Care Around High-pressure Fluid Lines

Avoid High-Pressure Fluids



MIF

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid injury from escaping fluid under pressure by stopping the engine and relieving pressure in the system before disconnecting or connecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.

SAFETY


Avoid Heating Near Pressurized Fluid Lines



MIF

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.

Service Machines Safely



MIF


Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.

Use Proper Tools

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards. Use power tools only to loosen threaded parts and fasteners. For loosening and tightening hardware, use the correct size tools. **DO NOT** use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches. Use only service parts meeting John Deere specifications.

Support Machine Properly and Use Proper Lifting Equipment



MIF

If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

Lifting heavy components incorrectly can cause severe injury or machine damage. Follow recommended procedure for removal and installation of components in the manual.

Work In Clean Area

Before starting a job:

1. Clean work area and machine.
2. Make sure you have all necessary tools to do your job.
3. Have the right parts on hand.
4. Read all instructions thoroughly; do not attempt shortcuts.

Using High Pressure Washers


Directing pressurized water at electronic/electrical components or connectors, bearings, hydraulic seals, fuel injection pumps or other sensitive parts and components may cause product malfunctions. Reduce pressure and spray at a 45 to 90 degree angle.

Illuminate Work Area Safely

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.

SAFETY

Work In Ventilated Area



MIF

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.

Warning: California Proposition 65 Warning

Gasoline engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Remove Paint Before Welding or Heating

Avoid potentially toxic fumes and dust. Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch. Do all work outside or in a well ventilated area. Dispose of paint and solvent properly. Remove paint before welding or heating: If you sand or grind paint, avoid breathing the dust. Wear an approved respirator. If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.


Avoid Harmful Asbestos Dust

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos. Keep bystanders away from the area.

Service Tires Safely



MIF

Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.


Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.

SAFETY


Avoid Injury From Rotating Blades, Augers and PTO Shafts



MIF

Keep hands and feet away while machine is running. Shut off power to service, lubricate or remove mower blades, augers or PTO shafts.

Handle Chemical Products Safely



MIF


Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques. Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

Dispose of Waste Properly

Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries. Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them. Do not pour waste onto the ground, down a drain, or into any water source. Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.

Parking Safely



MIF

1. Stop machine on a level surface, not on a slope.
2. Disengage and stop attachments.
3. Lower attachments to the ground.
4. Lock park brake.
5. Stop engine.
6. Remove key.
7. Wait for engine and all moving parts to stop before you leave the operator's station.
8. Close fuel shut-off valve, if your machine is equipped.

Live With Safety



MIF

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.

SPECIFICATIONS & INFORMATION TABLE OF CONTENTS

Table of Contents

Fastener Torques	9
Metric Fastener Torque Values	9
Inch Fastener Torque Values	10
O-Ring Seal Service Recommendations	11
Face Seal Fittings	
With Inch Stud Ends Torque	11
Face Seal Fittings	
With Metric Stud Ends Torque	12
O-Ring Face Seal Fittings	13
O-Ring Boss Fittings	13
Straight Fitting or Special Nut Torques	14
Metric Fastener Torque Value -	
Grade 7 (Special)	14
General Information	14
Gasoline	14
Gasoline Storage.....	15
4 - Cycle Gasoline Engine Oil	15
Break-In Engine Oil - 4-Cycle Gasoline.....	16
Hydrostatic Transmission	
and Hydraulic Oil	16
Alternative Lubricants.....	17
Synthetic Lubricants	17
Lubricant Storage	17
Mixing of Lubricants	17
Oil Filters	17
Serial Number Locations	18
Product Serial Number	18

SPECIFICATIONS & INFORMATION TABLE OF CONTENTS



SPECIFICATIONS & INFORMATION SPECIFICATIONS

Specifications

General Vehicle Specifications

Engine

Make.....	Briggs and Stratton Vanguard
Type.....	Gasoline
Model.....	303447
Cylinders.....	2
Displacement.....	480 cc (29.3 cu in.)
Stroke/Cycle.....	4 Cycle
Bore.....	68 mm (2.68 in.)
Stroke.....	66 mm (2.60 in.)
Compression Ratio.....	8.4:1
Valving.....	Overhead Valves
Lubrication.....	Pressurized
Oil Filter.....	Full Flow Spin On Filter
Engine Oil Capacity.....	1.4 L (1.5 qt)
Cooling System.....	Air Cooled
Air Cleaner.....	Dual Element; foam and paper
Muffler.....	Horizontal Discharge
Fuel Filter.....	Replaceable In-Line
Fuel.....	Gasoline (minimum 87 octane)
Fuel Tank Capacity.....	14.8 L (3.9 gal)

Electrical

Ignition.....	Electronic CDI
Type of Starter.....	Solenoid Shift
Charging System.....	Flywheel Alternator
Battery Type.....	12 Volt, 38 Amp Hour
Alternator.....	16 amp flywheel alternator

Drive Train

Type.....	Hydrostatic
Hydraulic Fluid Capacity.....	12.2 L (12.9 qt)
Travel Speed (Forward).....	0-16 km/h (0-10 mph)
Travel Speed (Reverse).....	0-6 km/h (0-4 mph)

Steering

Type.....	Mechanical, Roller-Chain and Sprocket
Ratio.....	8:1
Steering Wheel Diameter.....	355 mm (14 in.)
Turns (Lock to Lock).....	3.0
Maximum Torque Required to Turn.....	14 N•m (10 lb-ft)
Expected Operating Grade.....	20% (11.3 Degrees)

Brakes

Brake Location/Type.....	Transaxle, Internal
Parking Brake.....	Brake Locking Lever

SPECIFICATIONS & INFORMATION FASTENER TORQUES

Fastener Torques

Metric Fastener Torque Values

Property Class and Head Markings				
Property Class and Nut Markings				

MIF

SIZE	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated a		Dry a		Lubricated a		Dry a		Lubricated a		Dry a		Lubricated a		Dry a	
	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft
M6	4.8	3.5	6	4.5	9	6.5	11	8.5	13	9.5	17	12	15	11.5	19	14.5
M8	12	8.5	15	11	22	16	28	20	32	24	40	30	37	28	47	35
M10	23	17	29	21	43	32	55	40	63	47	80	60	75	55	95	70
M12	40	29	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	47	80	60	120	88	150	110	175	130	225	165	205	150	260	109
M16	100	73	125	92	190	140	240	175	275	200	350	225	320	240	400	300
M18	135	100	175	125	260	195	330	250	375	275	475	350	440	325	560	410
M20	190	140	240	180	375	275	475	350	530	400	675	500	625	460	800	580
M22	260	190	330	250	510	375	650	475	725	540	925	675	850	625	1075	800
M24	330	250	425	310	650	475	825	600	925	675	1150	850	1075	800	1350	1000
M27	490	360	625	450	950	700	1200	875	1350	1000	1700	1250	1600	1150	2000	1500
M30	675	490	850	625	1300	950	1650	1200	1850	1350	2300	1700	2150	1600	2700	2000
M33	900	675	1150	850	1750	1300	2200	1650	2500	1850	3150	2350	2900	2150	3700	2750
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2750	4750	3500

DO NOT use these hand torque values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only and include a $\pm 10\%$ variance factor. Check tightness of fasteners periodically. DO NOT use air powered wrenches.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same grade. Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

When bolt and nut combination fasteners are used, torque values should be applied to the NUT instead of the bolt head.









Tighten toothed or serrated-type lock nuts to the full torque value.

a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated (yellow dichromate - Specification JDS117) without any lubrication.

Reference: JDS - G200.

SPECIFICATIONS & INFORMATION FASTENER TORQUES

Inch Fastener Torque Values

SAE Grade and Head Markings	1 or 2 ^b No Marks 	5 5.1 5.2 	8 8.2 
SAE Grade and Nut Markings	2 No Marks 	5  	8  

MIF

SIZE	Grade 1				Grade 2b				Grade 5, 5.1 or 5.2				Grade 8 or 8.2			
	Lubricated a		Dry a		Lubricated a		Dry a		Lubricated a		Dry a		Lubricated a		Dry a	
	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft
1/4	3.7	2.8	4.7	3.5	6	4.5	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.5	10	7	12	9	15	11	20	15	25	18	28	21	35	26
3/8	14	10	17	13	22	16	27	20	35	26	44	33	50	36	63	46
7/16	22	16	28	20	35	26	44	32	55	41	70	52	80	58	100	75
1/2	33	25	42	31	53	39	67	50	85	63	110	80	120	90	150	115
9/16	48	36	60	45	75	56	95	70	125	90	155	115	175	130	225	160
5/8	67	50	85	62	105	78	135	100	170	125	215	160	215	160	300	225
3/4	120	87	150	110	190	140	240	175	300	225	375	280	425	310	550	400
7/8	190	140	240	175	190	140	240	175	490	360	625	450	700	500	875	650
1	290	210	360	270	290	210	360	270	725	540	925	675	1050	750	1300	975
1-1/8	470	300	510	375	470	300	510	375	900	675	1150	850	1450	1075	1850	1350
1-1/4	570	425	725	530	570	425	725	530	1300	950	1650	1200	2050	1500	2600	1950
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2150	1550	2700	2000	3400	2550
1-1/2	1000	725	1250	925	990	725	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

DO NOT use these hand torque values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only and include a ±10% variance factor. Check tightness of fasteners periodically. DO NOT use air powered wrenches.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same grade. Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

When bolt and nut combination fasteners are used, torque values should be applied to the NUT instead of the bolt

head.

Tighten toothed or serrated-type lock nuts to the full torque value.

a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated (yellow dichromate - Specification JDS117) without any lubrication.


b "Grade 2" applies for hex cap screws (Not Hex Bolts) up to 152 mm (6 in.) long. "Grade 1" applies for hex cap screws over 152 mm (6 in.) long, and for all other types of bolts and screws of any length.

Reference: JDS - G200

SPECIFICATIONS & INFORMATION O-RING SEAL SERVICE

O-Ring Seal Service Recommendations

Face Seal Fittings With Inch Stud Ends Torque




MIF

Nominal Tube OD/Hose ID				Face Seal Tube/Hose End					O-Ring Stud Ends			
Metric Tube OD	Inch Tube OD			Thread Size	Tube Nut/ Swivel Nut Torque		Bulkhead Lock Nut Torque		Thread Size	Straight Fitting or Lock Nut Torque		
	mm	Dash Size	in.		mm	in.	N•m	lb-ft		N•m	lb-ft	in.
5	-3	0.188	4.76						3/8-24	8	6	
6	-4	0.250	6.35	9/16-18	16	12	12	9	7/16-20	12	9	
8	-5	0.312	7.94						1/2-20	16	12	
10	-6	0.375	9.52	11/16-16	24	18	24	18	9/16-18	24	18	
12	-8	0.500	12.70	13/16-16	50	37	46	34	3/4-16	46	34	
16	-10	0.625	15.88	1-14	69	51	62	46	7/8-14	62	46	
19	-12	0.750	19.05	1-3/16-12	102	75	102	75	1-1/16-12	102	75	
22	-14	0.875	22.22	1-3/16-12	102	75	102	75	1-3/16-12	122	90	
25	-16	1.000	25.40	1-7/16-12	142	105	142	105	1-5/16-12	142	105	
32	-20	1.25	31.75	1-11/16-12	190	140	190	140	1-5/8-12	190	140	
38	-24	1.50	38.10	2-12	217	160	217	160	1-7/8-12	217	160	

NOTE: Torque tolerance is +15%, -20%

SPECIFICATIONS & INFORMATION O-RING SEAL SERVICE

Face Seal Fittings With Metric Stud Ends Torque




Nominal Tube OD/Hose ID				Face Seal Tube/Hose End						O-Ring Stud Ends, Straight Fitting or Lock Nut					
Metric Tube OD	Inch Tube OD			Thread Size	Hex Size	Tube Nut/ Swivel Nut Torque		Bulkhead Lock Nut Torque		Thread Size	Hex Size	Steel or Gray Iron Torque		Aluminum Torque	
	Dash Size	in.	mm			in.	mm	N•m	lb-ft			N•m	lb-ft	mm	mm
6	-4	0.250	6.35	9/16-18	17	16	12	12	9	M12X1.5	17	21	15.5	9	6.6
8	-5	0.312	7.94												
										M14X1.5	19	33	24	15	11
10	-6	0.375	9.52	11/16-16	22	24	18	24	18	M16X1.5	22	41	30	18	13
12	-8	0.500	12.70	13/16-16	24	50	37	46	34	M18X1.5	24	50	37	21	15
16	-10	0.625	15.88	1-14	30	69	51	62	46	M22X1.5	27	69	51	28	21
	-12	0.750	19.05	1-3/16-12	36	102	75	102	75	M27X2	32	102	75	46	34
22	-14	0.875	22.22	1-3/16-12	36	102	75	102	75	M30X2	36				
25	-16	1.000	25.40	1-7/16-12	41	142	105	142	105	M33X2	41	158	116	71	52
28										M38X2	46	176	130	79	58
32	-20	1.25	31.75	1-11/16-12	50	190	140	190	140	M42X2	50	190	140	85	63
38	-24	1.50	38.10	2-12	60	217	160	217	160	M48X2	55	217	160	98	72

NOTE: Torque tolerance is +15%, -20%

SPECIFICATIONS & INFORMATION O-RING SEAL SERVICE

O-Ring Face Seal Fittings




1. Inspect the fitting sealing surfaces (A). They must be free of dirt or defects.
2. Inspect the O-ring (B). It must be free of damage or defects.
3. Lubricate O-rings and install into groove using petroleum jelly to hold in place during assembly.
4. Index angle fittings and tighten by hand pressing joint together to insure O-ring remains in place.

IMPORTANT: Avoid damage! DO NOT allow hoses to twist when tightening fittings. Use two wrenches to tighten hose connections; one to hold the hose, and the other to tighten the swivel fitting.


5. Tighten fitting or nut to torque value shown on the chart per dash size stamped on the fitting.

O-Ring Boss Fittings

1. Inspect boss O-ring boss seat. It must be free of dirt and defects. If repeated leaks occur, inspect for defects with a magnifying glass. Some raised defects can be removed with a slip stone.



2. Put hydraulic oil or petroleum jelly on the O-ring (B). Place electrical tape over the threads to protect O-ring from nicks. Slide O-ring over the tape and into the groove (A) of fitting. Remove tape.



3. For angle fittings, loosen special nut (D) and push special washer (C) against threads so O-ring can be installed into the groove of fitting.
4. Turn fitting into the boss by hand until special washer or washer face (straight fitting) contacts boss face and O-ring is squeezed into its seat.
5. To position angle fittings (E), turn the fitting counter-clockwise a maximum of one turn.
6. Tighten straight fittings to torque value shown on chart. For angle fittings, tighten the special nut to value shown in the chart while holding body of fitting with a wrench.

SPECIFICATIONS & INFORMATION GENERAL INFORMATION

Straight Fitting or Special Nut Torques

Thread Size	Torque ^a		Number of Flats ^b
	N•m	lb-ft	
3/8-24 UNF	8	6	2
7/16-20 UNF	12	9	2
1/2-20 UNF	16	12	2
9/16-18 UNF	24	18	2
3/4-16 UNF	46	34	2
7/8-14 UNF	62	46	1-1/2
1-1/16-12 UN	102	75	1
1-3/16-12 UN	122	90	1
1-5/16-12 UN	142	105	3/4
1-5/8-12 UN	190	140	3/4
1-7/8-12 UN	217	160	1/2

^aTorque tolerance is \pm 10 percent.

^bTo be used if a torque wrench cannot be used. After tightening fitting by hand, put a mark on nut or boss; then tighten special nut or straight fitting the number of flats shown.

Metric Fastener Torque Value - Grade 7 (Special)

Size	Steel or Gray Iron Torque	Aluminum Torque
	N•m (lb-ft)	N•m (lb-ft)
M6	11 (8)	8 (6)
M8	24 (18)	19 (14)
M10	52 (38)	41 (30)
M12	88 (65)	70 (52)
M14	138 (102)	111 (82)
M16	224 (165)	179 (132)

General Information

Gasoline

4 - Cycle Engines



CAUTION: Avoid Injury! Gasoline is **HIGHLY FLAMMABLE**, handle it with care. **DO NOT** refuel machine while: indoors, always fill gas tank outdoors; machine is near an open flame or sparks; engine is running, **STOP** engine; engine is hot, allow it to cool sufficiently first; smoking.

Help prevent fires: fill gas tank to bottom of filler neck only; be sure fill cap is tight after fueling; clean up any gas spills IMMEDIATELY; keep machine clean and in good repair - free of excess grease, oil, debris, and faulty or damaged parts; any storage of machines with gas left in tank should be in an area that is well ventilated to prevent possible igniting of fumes by an open flame or spark, this includes any appliance with a pilot light. To prevent fire or explosion caused by STATIC ELECTRIC DISCHARGE during fueling: •ONLY use a clean, approved POLYETHYLENE PLASTIC fuel container and funnel WITHOUT any metal screen or filter.

To avoid engine damage:


- DO NOT mix oil with gasoline;
- **ONLY use clean, fresh unleaded gasoline with an octane rating (anti-knock index) of 87 or higher;**
- fill gas tank at the end of each day's operation to help prevent condensation from forming inside a partially filled tank;
- keep up with specified service intervals.

Use of alternative oxygenated, gasohol blended, unleaded gasoline is acceptable as long as:

- the ethyl or grain alcohol blends **DO NOT** exceed 10% by volume or
- methyl tertiary butyl ether (MTBE) blends **DO NOT** exceed 15% by volume

RFG (reformulated) gasoline is acceptable for all machines designed for use of regular unleaded fuel. Older machines (that were designed for leaded fuel) may see some accelerated valve and seat wear.

SPECIFICATIONS & INFORMATION GENERAL INFORMATION



MIF

IMPORTANT: Avoid damage! California Proposition 65 Warning: Gasoline engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Gasoline Storage

IMPORTANT: Avoid damage! Keep all dirt, scale, water or other foreign material out of gasoline.

Keep gasoline stored in a safe, protected area. Storage of gasoline in a clean, properly marked ("UNLEADED GASOLINE") POLYETHYLENE PLASTIC container WITHOUT any metal screen or filter is recommended. DO NOT use de-icers to attempt to remove water from gasoline or depend on fuel filters to remove water from gasoline. Use a water separator installed in the storage tank outlet. BE SURE to properly discard unstable or contaminated gasoline. When storing the machine or gasoline, it is recommended that you add **John Deere Gasoline Conditioner and Stabilizer (TY15977)** or an equivalent to the gasoline. BE SURE to follow directions on container and to properly discard empty container.

4 - Cycle Gasoline Engine Oil

Use the appropriate oil viscosity based on the expected air temperature range during the period between recommended oil changes. Operating outside of these recommended oil air temperature ranges may cause premature engine failure.

The following John Deere oils are PREFERRED:


- **PLUS - 4@ - SAE 10W-40;**
- **TORQ - GARD SUPREME® - SAE 5W-30.**

The following John Deere oils are **also recommended**, based on their specified temperature range:

- **TURF - GARD® - SAE 10W-30;**
- **PLUS - 4@ - SAE 10W-30;**
- **TORQ - GARD SUPREME® - SAE 30.**


Other oils may be used if above John Deere oils are not available, provided they meet one of the following specifications:

- SAE 10W-40 - API Service Classifications SG or higher;
- SAE 5W-30 - API Service Classification SG or higher;
- SAE 10W-30 - API Service Classifications SG or higher;
- SAE 30 - API Service Classification SC or higher.



MIF

Hydrostatic Transmission and Hydraulic Oil



MX10362

Use the following oil viscosity based on the air temperature range. Operating outside of the recommended oil air temperature range may cause premature hydrostatic transmission failure.

IMPORTANT: Avoid damage! Only use a quality oil in this transmission. Do not mix any other oils in this transmission. Do not use BIO-HY-GARD® in this transmission. Do not use “Type F” (Red) Automatic Transmission Fluid in this transmission.

The following oil is preferred:

- JD Plus 50 15W-40

The following oil is also recommended:

- SAE 15W-40

The following oil is allowable:

- JD Plus 50 0W-40 Synthetic

Oil must meet the following:

- API Service Classification SG or higher

Alternative Lubricants

Use of alternative lubricants could cause reduced life of the component.

If alternative lubricants are to be used, it is recommended that the factory fill be thoroughly removed before switching to any alternative lubricant.

Synthetic Lubricants

Synthetic lubricants may be used in John Deere equipment if they meet the applicable performance requirements (industry classification and/or military specification) as shown in this manual.

The recommended air temperature limits and service or lubricant change intervals should be maintained as shown in the operator’s manual, unless otherwise stated on lubricant label.

Avoid mixing different brands, grades, or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements. Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance.

Lubricant Storage

All machines operate at top efficiency only when clean lubricants are used. Use clean storage containers to handle all lubricants. Store them in an area protected from dust, moisture, and other contamination. Store drums on their sides. Make sure all containers are properly marked as to their contents. Dispose of all old, used containers and their contents properly.

Mixing of Lubricants

In general, avoid mixing different brands or types of lubricants. Manufacturers blend additives in their lubricants to meet certain specifications and performance requirements. Mixing different lubricants can interfere with the proper functioning of these additives and lubricant properties which will downgrade their intended specified performance.

Oil Filters

IMPORTANT: Avoid damage! Filtration of oils is critical to proper lubrication performance. Always change filters regularly.

The following John Deere oil filters are PREFERRED:

- AUTOMOTIVE AND LIGHT TRUCK ENGINE OIL FILTERS.

Most John Deere filters contain pressure relief and anti-drainback valves for better engine protection.


Other oil filters may be used if above recommended John Deere oil filters are not available, provided they meet the following specification:

- ASTB Tested In Accordance With SAE J806.


SPECIFICATIONS & INFORMATION SERIAL NUMBER LOCATIONS

Serial Number Locations

Product Serial Number



MX32528



MX32552

The product identification number (A) is located on the rear right-hand side frame.

Engine serial number (B) is located on the side of the engine housing.

Hydraulic pump product identification number (C) is located on the top of pump.

ENGINE - GAS TABLE OF CONTENTS

Table of Contents

Specifications21

General Specifications	21
Test and Adjustment Specifications	21
Repair Specifications.....	21
Torque Specifications (Alphabetical).....	23

Diagnostics25

Engine Will Not Start	25
-----------------------------	----

Tests and Adjustments27

Throttle Cable Adjustment.....	27
Choke Cable Adjustment.....	27
Fuel Shutoff Solenoid Test	27
Carburetor Adjustment	28
Governor Adjustment	29
Compression Test	30
Valve Clearance Adjustment	31
Engine Oil Pressure Test	32
Armature Air Gap Adjustment	33

Repair.....34

Blower Housing and Fan Removal and Installation	34
Air Cleaner Removal and Installation.....	34
Throttle and Choke Cable Removal and Installation	35
Carburetor Removal and Installation.....	36
Carburetor Inspection.....	37
Carburetor Disassembly.....	38
Carburetor Assembly.....	39
Engine Removal and Installation.....	41
Air Guides Removal and Installation	43
Intake Manifold Removal and Installation.....	43
Cylinder Head Removal and Installation	43
Cylinder Head Inspection and Repair.....	46
Valve Removal	46
Valve Inspection and Repair	46
Valve Guide Ream	47
Valve Installation	48
Piston, Rings & Rod Removal and Installation	48
Piston Inspection	49
Connecting Rod Inspection	49
Assemble Piston Rod	50
Cylinder Bore Inspection	52
Cylinder Bore Honing	52
Cylinder Bore Cleaning	52

Resizing Cylinder Bore	53
Flywheel Removal and Installation	53
Crankshaft Removal and Installation	54
Magneto Bearing Inspection.....	57
PTO and Cam Bearing Inspection.....	58
Breather Valve Service.....	58
Oil Pump Removal.....	59
Starting Motor Removal and Installation.....	60
Starting Motor Disassembly	61
Starting Motor Assembly.....	63
Starting Motor Pinion Gear Replacement....	64

ENGINE - GAS TABLE OF CONTENTS



ENGINE - GAS SPECIFICATIONS

Specifications

General Specifications

Make	Briggs and Stratton Vanguard
Type	Gasoline
Model	303447
Cylinders	2
Displacement	480 cc (29.3 cu in.)
Stroke/Cycle	4 Cycle
Bore	68 mm (2.68 in.)
Stroke	66 mm (2.60 in.)
Compression Ratio	8.4:1
Valving	Overhead Valves
Lubrication	Pressurized
Oil Filter	Full Flow Spin On Filter
Engine Oil Capacity	1.4 L (1.5 qt)
Cooling System	Air Cooled
Air Cleaner	Dual Element; foam and paper
Muffler	Horizontal Discharge
Fuel Filter	Replaceable In-Line
Fuel	Gasoline (minimum 87 octane)
Fuel Tank Capacity	14.8 L (3.9 gal)

Test and Adjustment Specifications

Armature Air Gap	0.20 - 0.30 mm (0.008 - 0.012 in.)
Spark Plug Gap	0.76 mm (0.030 in.)
Valve Clearance	0.10 - 0.15 mm (0.004 - 0.006 in.)
Valve Guide Depth	0.7 mm (0.281 in.)
Slow Idle	1900 ± 50 rpm
Fast Idle	3200 ± 100 rpm
Choke Knob-to-Cable-Mount Clearance	2 - 3 mm (0.08 - 0.12 in.)
Carburetor SLOW Idle Mixture Screw Initial Setting	1-3/8 in. turns
Oil Pump Operating Pressure	69 - 517 kPa (10 - 75 psi)

Repair Specifications

Valves:

Valve Guide:

Standard Dimension	6.01 - 6.02 mm (0.236 - 0.237 in.)
Wear Limit	6.05 mm (0.238 in.)

Valve Stem Standard Dimension:

Intake	5.94 - 5.96 mm (0.234 - 0.235 in.)
Exhaust	5.94 - 5.95 mm (0.234 - 0.235 in.)

Valve Stem Wear Limit:

ENGINE - GAS SPECIFICATIONS

Intake	5.92 mm (0.233 in.)
Exhaust	5.91 mm (0.328 in.)
Valve Seat Width	1.2 - 1.6 mm (0.047 - 0.062 in.)
Valve Margin	0.8 mm (0.030 in.)
Valve Face Angle	45°
Valve Seat Narrowing Angle	30°

Cylinder Bore, Pistons and Rings:

Cylinder Bore:

Standard Dimension	68.0 - 68.03 mm (2.677 - 2.678 in.)
Wear Limit	68.10 mm (2.681 in.)

Piston Pin:

Standard Dimension	17.07 - 17.08 mm (0.672 - 0.673 in.)
Wear Limit	17.06 mm (0.672 in.)

Piston Pin Bore:

Standard Dimension	17.09 - 17.10 mm (0.673 - 0.674 in.)
Wear Limit	17.12 mm (0.674 in.)

Ring End Gap:

Standard Dimension	0.20 - 0.40 mm (0.008 - 0.016 in.)
Wear Limit	0.76 mm (0.030 in.)

Compression Ring Groove Wear Limit (New Ring Installed) 0.10 mm (0.004 in.)

Oil Ring Groove Clearance Wear Limit (New Ring Installed) 0.20 mm (0.008 in.)

Connecting Rod and Crankshaft:

Connecting Rod Crankpin:

Standard Dimension	37.06 - 37.08 mm (1.459 - 1.460 in.)
Wear Limit	37.11 mm (1.461 in.)

Connecting Rod Piston Pin Bearing:

Standard Dimension	17.09 - 17.10 mm (0.6728 - 0.6732 in.)
Wear Limit	17.12 mm (0.674 in.)

Crankshaft PTO Journal:

Standard Dimension	34.96 - 34.97 mm (1.376 - 1.377 in.)
Wear Limit	34.92 mm (1.375 in.)

Crankshaft Magneto Journal:

Standard Dimension	34.99 - 35.01 mm (1.3776 - 1.378 in.)
Wear Limit	34.95 mm (1.376 in.)

Magneto Bearing:

Standard Dimension	30.03 - 30.06 mm (1.1825 - 1.1835 in.)
Wear Limit	30.08 mm (1.184 in.)

ENGINE - GAS SPECIFICATIONS

PTO Bearing:

Standard Dimension..... 35.04 - 35.05 mm (1.379 - 1.380 in.)

Wear Limit 35.07 mm (1.381 in.)

Crankshaft Crankpin Journal:

Standard Dimension..... 37.0 - 37.02 mm (1.456 - 1.457 in.)

Wear Limit 36.95 mm (1.455 in.)

Crankshaft End Play..... 0.05 - 0.76 mm (0.002 - 0.030 in.)

Cam Gear PTO Journal:

Standard Dimension..... 19.94 - 19.96 mm (0.785 - 0.786 in.)

Wear Limit 19.92 mm (0.784 in.)

Cam Gear Magneto Journal:

Standard Dimension..... 15.95 - 15.97 mm (0.628 - 0.629 in.)

Wear Limit 15.93 mm (0.627 in.)

Cam Lobe:

Standard Dimension..... 30.33 - 30.53 mm (1.194 - 1.202 in.)

Wear Limit 30.25 mm (1.191 in.)

Cam Bearing (Magneto Side):

Standard Dimension..... 16.0 - 16.025 mm (0.630 - 0.631 in.)

Wear Limit 16.08 mm (0.633 in.)

Cam Bearing (PTO Side):

Standard Dimension..... 20.0 - 20.02 mm (0.787 - 0.788 in.)

Wear Limit 20.04 mm (0.789 in.)

Torque Specifications (Alphabetical)

Alternator to Cylinder Block 2.2 Nm (20 lb in.)

Air Cleaner Base to Carburetor..... 7 N•m (65 lb-in.)

Clutch to Crankshaft Bolt 68 N•m (50 lb-ft)

Connecting Rod Cap Screws 13 N•m (115 lb-in.)

Clutch Mounting Bolt..... 75 N•m (55 lb-ft)

Crankcase Cover 17 N•m (150 lb-in.)

Cylinder Head Cap Screws 19 N•m (165 lb-in.)

Cylinder Shield 7 N•m (65 lb-in.)

Engine Mounting Bolts 32 N•m (24 lb-ft)

Exhaust Manifold 17 N•m (150 lb-in.)

Flywheel Nut 170 N•m (125 lb-ft)

Fuel Shutoff Solenoid 5 N•m (45 lb-in.)

Oil Breather Mounting Bolt 3 N•m (30 lb-in.)

Oil Filter Adaptor Mounting Bolts..... 7 N•m (62 lb-in.)

Oil Pump Mounting Screws 7 N•m (62 lb-in.)

ENGINE - GAS SPECIFICATIONS

Rocker Arm Adjustment Lock Nut	7 N•m (62 lb-in.)
Rocker Mounting Studs	11 N•m (100 lb-in.)
Spark Plug	20 N•m (180 lb-in.)
Starting Motor Mounting Bolts	16 N•m (140 lb-in.)
Valve Cover Nuts	8 N•m (70 lb-in.)

ENGINE - GAS DIAGNOSTICS

Diagnostics

Engine Will Not Start



CAUTION: Avoid Injury! Be aware! The engine may start to rotate at any time. Keep hands away from all moving parts when testing.

NOTE: To test specific electrical components, see Electrical section and refer to either Diagnostics or Tests and Adjustments for further guidance.

Symptom: Engine Will Not Crank

(1) Is the operator seat switch closed and the park brake set?

Yes - Go to next step. See "Cranking Circuit Operation" on page 77 in the Electrical section.

No - Operator on seat and set park brake.

(2) Is battery voltage 12.4 volts or higher?

Yes - Go to next step.

No - Charge battery and perform no-load test. Go to next step.

(3) Is battery voltage 12.4 volts or higher?

Yes - Go to next step.

No - Replace battery.

(4) Does starter solenoid click when ignition switch is turned to start position?

Yes - Check starter motor.

No - Check electrical system.



CAUTION: Avoid Injury! Do not rotate engine with starter if the spark plugs are removed. Gasoline spray from the open cylinders may be ignited by ignition spark and cause an explosion or fire.

NOTE: Perform a visual inspection first to determine if battery cables are tight and not corroded and if battery is of sufficient size to turn the engine over at minimum cranking speed of 350 rpm.

Symptom: Engine Cranks But Will Not Start

(1) Is battery voltage 12.4 volts or higher?

Yes - Go to next step.

Symptom: Engine Cranks But Will Not Start

No - Charge battery and perform no-load test. Go to next step.

(2) Does fuel shutoff solenoid click when ignition switch is turned to start/run?

Yes - Go to next step.

No - Defective fuel shutoff solenoid, switch or wiring. See Electrical section.

(3) Does engine crank slow?

Yes - Remove spark plugs and turn the engine over by hand. Go to next step.

No - Go to next step.

(4) Is the engine hard to turn over by hand?

Yes - Pistons or other internal components binding.

No - Starter motor possibly defective. Repair or replace as needed.

(5) Is the choke operating properly?

Yes - Go to next step.

No - Adjust choke cable.

(6) Do spark plugs have strong blue spark?

Yes - Go to next step.

No - Possible defective spark plugs, magneto shorted to ground, flywheel magnet weak, or ignition coil air gap not adjusted. See Electrical section.

(7) Are tappets adjusted properly.

Yes - Go to next step.

No - Adjust tappets.

(8) Is engine getting fuel?

Yes - Check air cleaner, fuel mixture, possible contaminated fuel, or stuck float needle.

No - Check fuel shutoff valve, fuel lines, fuel pump, and engine vacuum.

Symptom: Engine Makes High Whining Sound

(1) Are the starter gears engaging and disengaging correctly?

Yes - Go to next step.

No - Check starting motor gears for correct engagement and disengagement. See "Starting Motor Removal and Installation" on page 60.

(2) Are the cam and crank gears engaging correctly?

ENGINE - GAS DIAGNOSTICS

Product: John Deere 1200 Hydro Bunker and Field Rake Service Repair Technical Manual

Full Download: <https://www.bobmanualstore.com/downloads/john-deere-1200-hyd>

Symptom: Engine Makes High Whining Sound

No - Check cam shaft end play.

Sample manual. Download All 150 pages at:

<https://www.bobmanualstore.com/downloads/john-deere-1200-hydro-bunker-and-field-rake-service-repair-technical-manual/>