

Product: John Deere 9400,9500,9600 Combines Tractor Service Repair Technical Manual  
Full Download: <https://www.bobmanualstore.com/downloads/john-deere-94009500-9600-combines-tractor-service-repair-technical-manual/>

# 9400, 9500, and 9600 Combines Repairs

**John Deere Harvester Works**  
**TM1401 (28JUL97)**

LITHO IN U.S.A.  
ENGLISH

Sample manual. Download All 1235 pages at:

<https://www.bobmanualstore.com/downloads/john-deere-940095009600-combines-tractor-service-repair-technical-manual/>

Product: John Deere 9400,9500,9600 Combines Tractor Service Repair Technical Manual  
Full Download: <https://www.bobmanualstore.com/downloads/john-deere-94009500-9600-combines-tractor-service-repair-technical-manual/>

**9400, 9500, and  
9600 Combines  
Repairs**

**TM1401 (28JUL97)**



Sample manual. Download All 1235 pages at:  
<https://www.bobmanualstore.com/downloads/john-deere-940095009600-combines-tractor-service-repair-technical-manual/>

# Introduction

## FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

# Contents

## SECTION 10—GENERAL

- Group 05—Safety
- Group 10—Identification Number Location
- Group 15—Specifications
- Group 20—Tune Up and Adjustment
- Group 25—Fuels and Lubricants

## SECTION 20—ENGINE

- Group 05—Remove and Install Engine
- Group 10—Cooling System
- Group 15—Lower Engine Repair

## SECTION 30—FUEL AND AIR REPAIR

- Group 05—Air Intake System
- Group 10—Diesel Fuel System

## SECTION 40—ELECTRICAL SYSTEM

- Group 05—Components
- Group 10—Bulbs and Switches
- Group 15—Batteries
- Group 20—Harness and Connector Repair
- Group 25—Gauges and Monitors
- Group 30—Wiper and Radio
- Group 35—Alternator
- Group 40—Starting Motor
- Group 45—Electrical Engine Control

## SECTION 50—POWER TRAIN REPAIR

- Group 05—Transmission and Differential
- Group 10—Ring and Pinion Final Drive
- Group 15—Planetary Final Drive
- Group 20—Hydrostatic System
- Group 25—Cam Lobe Motor
- Group 30—Tires and Wheels

## SECTION 60—Power Steering and Brakes

- Group 05—Steering
- Group 10—Brakes

## SECTION 70—HYDRAULIC REPAIR

- Group 05—Hydraulic Reservoir
- Group 10—Hydraulic Pumps
- Group 15—Hydraulic Valves

- Group 20—Hydraulic Cylinders
- Group 25—Motors
- Group 30—Accumulator
- Group 35—Reel/Belt Pickup Pump Drive

## SECTION 80—SEPARATOR SHELL

- Group 05—Gull Wing Doors

## SECTION 90—OPERATOR STATION REPAIR

- Group 05—Air Conditioning System (R-12)—Type A
- Group 10—Air Conditioning System (R134A)—Type B
- Group 15—System Components
- Group 20—Cab

## SECTION 110—FEEDER HOUSE REPAIR

- Group 05—Feeder House/Conveyor
- Group 10—Feeder House Conveyor Drum
- Group 15—Conveyor Shaft and Slip Clutch
- Group 20—Feeder House Drives and Reverser Gear Case
- Group 25—CONTOUR MASTER Platform Driveshafts
- Group 30—CONTOUR MASTER Tilt Cylinder
- Group 35—CONTOUR MASTER Tilt Frame
- Group 40—CONTOUR MASTER Feeder House

## SECTION 120—SEPARATOR

- Group 05—Separator Repair
- Group 10—Cylinder Drives
- Group 15—Straw Walkers and Crankshafts
- Group 20—Straw Chopper, Straw Spreader and Chaff Spreader
- Group 25—Shoe Supply Augers, Cleaning Fan and Chaffer and Sieve Frame
- Group 30—Tailings Elevator and Augers
- Group 35—Primary Countershaft Gearcase
- Group 40—Header Electromagnetic Clutch

Continued on next page

*All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

TM1401-19-28JUL97

COPYRIGHT© 1997  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved  
A John Deere ILLUSTRATION™ Manual  
Previous Editions  
Copyright 1994, 1992, 1989, 1988 Deere & Company

**SECTION 130—GRAIN TANK AND UNLOADING  
SYSTEM REPAIR**

10

Group 05—Grain Tank Cross Augers  
Group 10—Unloading Auger System Drives  
Group 15—Vertical Unloading Auger and Lower  
Gearcase

20

Group 20—Horizontal Unloading Auger and  
Gearcase  
Group 25—Upper Clean Grain Elevator  
Group 30—Grain Tank and Extensions  
Group 35—Clean Grain Elevator and Loading  
Auger Gear Case

30

**SECTION 140—ENGINE GEARCASE AND  
CONTROL VALVE REPAIR**

Group 05—Engine Gearcase and Valve

40

**SECTION 160—DIAL-A-MATIC HEADER HEIGHT  
CONTROL**

Group 05—Dial-A-Matic Header Height Control

**Index**

50

60

70

80

90

110

*Contents*

120

130

140

160

INDX

*Contents*

120

130

140

160

INDX

# Section 10 GENERAL

10

## Contents

	Page		Page
<b>Group 05—Safety</b> .....	10-05-1	Engine Coolant .....	10-25-3
<b>Group 10—Identification Number Location</b>		Liquid Coolant Conditioner .....	10-25-3
Combine Identification Number .....	10-10-1	Engine Oil .....	10-25-4
Transmission .....	10-10-1	Greases .....	10-25-7
Engine Serial Number for 9400 Combines ..	10-10-1	Lubricant Storage .....	10-25-7
Hydrostatic Drive Unit Pump .....	10-10-2	Alternative and Synthetic Lubricants .....	10-25-8
Hydrostatic Drive Unit Motor .....	10-10-2	Filter Part Numbers .....	10-25-8
Cam Lobe 4-Wheel Drive Motor .....	10-10-2		
Engine Gearcase .....	10-10-2		
Cab .....	10-10-3		
<b>Group 15—Specifications</b>			
Specifications—9400 Combines .....	10-15-1		
Operating Speeds—9400 Combines .....	10-15-3		
Ground Speeds (Separator Full Load) ..	10-15-4		
Specifications—9500 Combines .....	10-15-5		
Operating Speeds—9500 Combines .....	10-15-7		
Ground Speeds .....	10-15-8		
Specifications—9600 Combines .....	10-15-9		
Operating Speeds—9600 Combines .....	10-15-11		
Dimensions .....	10-15-14		
Metric Bolt and Cap Screw Torque			
Values .....	10-15-15		
Unified Inch Bolt and Cap Screw Torque			
Values .....	10-15-16		
O-Ring Boss Fitting Torque Chart .....	10-15-17		
Flat Face O-Ring Seal Fitting Torque			
Chart .....	10-15-18		
SAE Four Bolt Flange Fitting Torque			
Chart .....	10-15-19		
Prevent Hydraulic System Contamination .	10-15-20		
Check Oil Lines and Fittings .....	10-15-21		
<b>Group 20—Tune Up and Adjustment</b>			
Tune-Up and Adjustment .....	10-20-1		
Care and Maintenance of Belts .....	10-20-2		
Defective Belts .....	10-20-3		
Right-Hand Drives and Part Numbers ..	10-20-5		
Left-Hand Drives and Part Numbers .....	10-20-7		
<b>Group 25—Fuels and Lubricants</b>			
Diesel Fuel .....	10-25-1		
Fuel Storage .....	10-25-2		

*Contents*

10

### RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-03MAR93

T81389  
-JUN-07DEC88

10  
05  
1

### UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93

TS187  
-19-30SEP88

### HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



DX,FLAME -19-04JUN90


TS227  
-JUN-23AUG88

### PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



DX,SPARKS -19-03MAR93


-JUN-23AUG88  
TS204

### PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93

-JUN-23AUG88  
TS201

10  
05  
2

## PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.



10  
05  
3

-JUN-23/AUG88

T5203

DX,POISON -19-21APR93

10  
05  
4


### AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



-JUN-23AUG88


X9811

DX,FLUID -19-03MAR93

### PARK MACHINE SAFELY

Before working on the machine:

- Lower all equipment to the ground.
- Stop the engine and remove the key.
- Disconnect the battery ground strap.
- Hang a "DO NOT OPERATE" tag in operator station.



-JUN-24MAY89


TS230

DX,PARK -19-04JUN90

### SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



DX.LOWER -19-04JUN90

TS229 -JUN-23AUG88

10  
05  
5


### WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.




DX.WEAR -19-10SEP90

TS206 -JUN-23AUG88

### SERVICE MACHINES SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



DX.LOOSE -19-04JUN90


TS228 -JUN-23AUG88

10  
05  
6

### WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



DX,AIR -19-04JUN90

-JUN-23AUG88  
TS220

### ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.




DX,LIGHT -19-04JUN90

-JUN-23AUG88  
TS223

### REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.




DX,SIGNS1 -19-04JUN90

-JUN-23AUG88  
TS201

### USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



DX,LIFT -19-04JUN90

-JUN-23AUG88  
TS226

### SERVICE TIRES SAFELY


Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



10  
05  
7

-JUN-23AUG88

TS211

DX,RIM -19-24AUG90


### AVOID HARMFUL ASBESTOS DUST

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos.

Keep bystanders away from the area.



-JUN-23AUG88


TS220

DX,DUST -19-15MAR91

### WORK IN CLEAN AREA

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.



DX.CLEAN -19-04JUN90

T6642EJ -JUN-18OCT88

### PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

Disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.



DX.SERV -19-03MAR93

TS218 -JUN-23AUG88

### USE PROPER TOOLS

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



10  
05  
9

-JUN-08NOV/89

TS179

DX,REPAIR -19-04JUN90

### DISPOSE OF WASTE PROPERLY


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



-JUN-26NOV/90

TS1133

DX,DRAIN -19-03MAR93

### USE ADEQUATE SERVICE FACILITIES

Keep the service area clean and dry. Wet or oily floors are slippery. Wet spots can be dangerous when working with electrical equipment.

Make sure the service area is adequately vented.

Periodically check the shop exhaust system for leakage. Engine exhaust gas is dangerous.

Be sure all electrical outlets and tools are properly grounded.

Use adequate light for the job at hand.

Service the machine on a level, hard-surfaced area.

Use lifting equipment and safety stands which have adequate strength for the job being performed.

HX,1401,1005,A -19-11DEC92

### LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.



TS231  
-19-07OCT88

DX,LIVE -19-25SEP92

## Group 10 Identification Number Location

### COMBINE IDENTIFICATION NUMBER

Located on left-hand side above rear axle.




HX,1401,1010A -19-11DEC92

10  
10  
1

### TRANSMISSION (LATER UNITS)

Located on the side of the transmission.




HX,9000ID,C -19-27SEP96

-JUN-19OCT95  
H47136

### ENGINE SERIAL NUMBER FOR 9400 COMBINES

Located on rear side of engine.




HX,1401,1010B -19-11DEC92

-JUN-10OCT91  
H43939

### ENGINE SERIAL NUMBER FOR 9500, 9500 SIDEHILL, 9600 AND CTS COMBINES

The engine serial number is located on rear side of engine.



HX,1010,A -19-28AUG96


-JUN-11OCT88  
H39756

*Early Engine Shown*

10-10-2

### HYDROSTATIC DRIVE UNIT PUMP

Located on the side of the pump section.




1401,1010,D -19-12SEP91

-JUN-11OCT88  
H39676

### HYDROSTATIC DRIVE UNIT MOTOR

Located on top of the motor section.



1401,1010,E -19-12SEP91

-JUN-11OCT88  
H39328

### CAM LOBE 4-WHEEL DRIVE MOTOR

Located on top of motor.




1401,1010,F -19-12SEP91

-JUN-11OCT88  
H39677

### ENGINE GEARCASE

Located on the back side.




1401,1010,G -19-12SEP91

-JUN-11OCT88  
H39757

Identification Number Location/Cab

**CAB**

Located on door frame.



1401,1010,Y -19-12SEP91

10  
10  
3

-UN-27OCT89  
H41155

*Identification Number Location/Cab*

10  
10  
4

**SPECIFICATIONS—9400 COMBINES**

Engine (6359A)	Make ..... John Deere ( —640100) Model ..... 6359A Type ..... six-cylinder, in line, valve-in-head, diesel, turbocharged Brake Horsepower ..... (125 kW) (167 hp) Displacement ..... 5.9L (359 cu. in.) Bore and Stroke ..... 107 x 110 mm (4.20 x 4.33 in.) Firing Order ..... 1-5-3-6-2-4 Air Cleaner ..... Dry Type with Safety Element Thermostats (Two) ..... 82°C (180°F)
Engine (6068H)	Make ..... John Deere ( —640101) Model ..... 6068H Type ..... six-cylinder, in line, valve-in-head, diesel, turbocharged Brake Horsepower ..... 138 kW (185 hp) Displacement ..... 6.8L (414 cu. in.) Bore and Stroke ..... 107 x 110 mm (4.20 x 4.33 in.) Firing Order ..... 1-5-3-6-2-4 Air Cleaner ..... Dry Type with Safety Element Thermostats (Two) ..... 82°C (180°F)
Electrical System:	12 volt, negative ground with 90 amp alternator
Transmission:	three speeds
Brakes:	hydraulic shoe
Cylinder:	Types ..... rasp bar or spike tooth Diameter ..... 660 mm (26 in.) Width ..... 1362 mm (53-1/2 in.) Number of bars:    rasp bar ..... 10 spike tooth ..... 12
Concave:	Types ..... open bar or spike tooth Area ..... 8123 sq. cm (1259 sq. in.)
Beater:	Diameter ..... 394 mm (15-1/2 in.) Number of wings ..... 8
Beater Grate:	Type ..... open bar two-position adjustable Area ..... 5300 sq. cm (821-1/2 sq. in.)

10  
15  
1

HX,1401,1015,A -19-27NOV96

**SPECIFICATIONS—9400 COMBINES**

10  
15  
2

Finger Bar:	Type . . . . . adjustable	
	Area . . . . .	4780 sq. cm (741 sq. in.)
Separator:	Type . . . . . straw walkers	
	Width . . . . .	1391 mm (55 in.)
Cleaning Shoe:	Chaffer width . . . . .	1286 mm (51 in.)
	Chaffer length (with extension) . . . . .	1220 mm (45 in.)
	Sieve width . . . . .	1286 mm (51 in.)
	Sieve length . . . . .	1159 mm (46 in.)
	Precleaner width . . . . .	1286 mm (51 in.)
	Precleaner length . . . . .	840 mm (33 in.)
	Total area . . . . .	411 sq. cm (6370 sq. in.)
Straw Walkers:	Type . . . . . Lip	
	Number of walkers . . . . .	4
	Length . . . . .	4000 mm (157 in.)
	Total area . . . . .	556 sq. cm (8624 sq. in.)
Grain Tank:	Capacity . . . . .	6410L (182 bu.)
	Average Unloading Rate . . . . .	4200L/min. (120 bu./min.)
Weights:	Less header (base equipment on a Corn Combine) . . . . .	10 333 kg (22,780 lb.)
Capacities:	Fuel tank . . . . .	530L (140 gal.)
	Cooling system (with heater) . . . . .	36L (38 U.S. qts.)
	Engine crankcase (with filter) 6359A . . . . .	14L (14-1/2 U.S. qts.)
	Engine crankcase (with filter) 6068H . . . . .	18.9L (20 U.S. qts.)
	Transmission . . . . .	9.6L (10 U.S. qts.)
	Final Drives (each) . . . . .	8.0L (8.5 U.S. qts.)
	Feeder House Reverser Gearcase . . . . .	1.9L (2 U.S. qts.)
	Separator Drive Gearcase . . . . .	2.4L (2-1/2 U.S. qts.)
	Straw Walker Drive Gearcase . . . . .	0.7L (1-1/2 U.S. qts.)
	Dual-Range Cylinder Drive Gearcase . . . . .	1.9L (2 U.S. qts.)
	Engine Gearcase . . . . .	16L (17 U.S. qts.)
	Loading Auger Gearcase . . . . .	4.7L (5 U.S. qts.)
	Hydraulic/Hydrostatic Reservoir . . . . .	34L (36 U.S. qts.)
	Air Conditioning System . . . . .	2.2 kg (4.9 lb)

HX.1401,1015.B -19-13SEP94

**OPERATING SPEEDS—9400 COMBINES**

Speeds shown are average and can vary from combine to combine. Speeds are rated at high idle with separator engaged, no load.

Engine: Slow Speed, Separator Off	( -639,999 )	1200 rpm
	( 640,000- )	1350 rpm
Fast Speed, Separator Off	( -639,999 )	2550 rpm
Fast Speed, Separator Engaged	( 640,000- )	2350 rpm
Full Load Rated Speed	( -639,999 )	2400 rpm
	( 640,000- )	2200 rpm
Separator Drive Shaft Speed		1550 rpm
Main Countershaft Speed		1550 rpm
Hydrostatic Pump Speed:	Ring and Pinion Final Drives	3510 rpm
Cylinder Speed:	Grain Special	470-960 rpm
	Extended Single Range	300-980 rpm
	Extended Dual Range (High Range)	300-980 rpm
	Extended Dual Range (Low Range)	150-480 rpm
Feeder House Lower Shaft:	Fixed Speed	520 rpm
	Variable	520-715 rpm
Secondary Countershaft		530 rpm
Cleaning Fan:	Standard	750-1350 rpm
	Optional	500-980 rpm
Clean Grain Elevator		400 rpm
Tailings Elevator		430 rpm
Shoe Crankshaft		280 rpm
Straw Walkers		170 rpm
Unloading Auger Countershaft		1060 rpm
Loading Auger		460 rpm
Inner Grain Tank Unloading Augers:	Front	405 rpm
	Rear	380 rpm
Vertical and Horizontal Unloading Augers		440 rpm
Straw Chopper:	Low (Corn)	1595 rpm
	High (Grain)	2130 rpm
Straw Spreader Shaft		235 rpm
Shoe Grain Supply Augers Shaft		405 rpm

10  
15  
3

HX,1401,1010,B -19-27NOV96

**GROUND SPEEDS (SEPARATOR FULL LOAD)**

For 9400 Combines equipped with ring and pinion final drives.

	TIRE SIZE	2WD	4WD	Speed in Km/h (mph)		
				FIRST GEAR	SECOND GEAR	THIRD GEAR
	20.8x38 R1	X		5.9 (3.7)	11.1 (6.9)	29.4 (18.4)
	20.8x38 R1		X	4.8 (3.0)	7.7 (4.8)	13.4 ( 8.4)
(Australia Only)	24.5x32 R1	X		5.9 (3.7)	14.3 (9.0)	29.4 (18.4)
	24.5x32 R1	X		5.9 (3.7)	11.1 (6.9)	29.4 (18.4)
	24.5x32 R1		X	4.8 (3.0)	7.7 (4.8)	13.4 ( 8.4)
	24.5x32 R3	X		5.7 (3.6)	10.6 (6.7)	28.3 (17.6)
	30.5Lx32 R1	X		5.9 (3.7)	11.1 (6.9)	29.4 (18.4)
	30.5Lx32 R1		X	4.8 (3.0)	7.7 (4.8)	13.4 ( 8.4)
	30.5Lx32 R2	X		6.3 (3.9)	11.7 (7.2)	31.2 (19.3)
	30.5Lx32 R2		X	5.2 (3.2)	8.0 (5.0)	14.0 ( 8.7)
	30.5Lx32 R3	X		5.7 (3.6)	10.6 (6.7)	28.3 (17.6)

HX,1401,1010Z -19-11DEC92

10  
15  
4

**SPECIFICATIONS—9500 COMBINES**

Engine:                    Make . . . . . John Deere ( —640200)  
                               Model . . . . . 6076T  
                               Type . . . . . six-cylinder, in line, valve-in-head, diesel, turbocharged  
                               Brake Horsepower . . . . . 142 kW (190 hp)  
                               Displacement . . . . . 7.6L (466 cu. in.)  
                               Bore and Stroke . . . . . 116 x 121 mm (4.56 x 4.75 in.)  
                               Firing Order . . . . . 1-5-3-6-2-4  
                               Air Cleaner . . . . . Dry Type with Safety Element  
                               Thermostats (Two) . . . . . 82°C (180°F)

Engine:                    Make . . . . . John Deere (640201— )  
                               Model . . . . . 6076H  
                               Type . . . . . six-cylinder, in line, valve-in-head, diesel, turbocharged  
                               Brake Horsepower Corn and Rice Special . . . . . 175 to 186 kW (235 w/boost to 250)  
    Grain . . . . . 160 to 170 kW (215 w/boost to 228)  
                               Displacement . . . . . 7.6L (466 cu. in.)  
                               Bore and Stroke . . . . . 116 x 121 mm (4.56 x 4.75 in.)  
                               Firing Order . . . . . 1-5-3-6-2-4  
                               Air Cleaner . . . . . Dry Type with Safety Element  
                               Thermostats (Two) . . . . . 82°C (180°F)

Electrical System:      12 volt, negative ground with 90 amp alternator

Transmission:            three speeds

Brakes:                    hydraulic shoe

Cylinder:                Types . . . . . rasp bar or spike tooth  
                               Diameter . . . . . 660 mm (26 in.)  
                               Width . . . . . 1362 mm (53-1/2 in.)  
                               Number of bars:        rasp bar . . . . . 10  
    spike tooth . . . . . 12

Concave:                Types . . . . . open bar or spike tooth  
                               Area . . . . . 8123 sq. cm (1259 sq. in.)

Beater:                    Diameter . . . . . 394 mm (15-1/2 in.)  
                               Number of wings . . . . . 8

Beater Grate:            Type . . . . . open bar two-position adjustable  
                               Area . . . . . 5300 sq. cm (821.5 sq. in.)

HX,1401,1015,E -19-27NOV96

10  
15  
5

**SPECIFICATIONS—9500 COMBINES**

10  
15  
6

Finger Bar:	Type . . . . . adjustable	
	Area . . . . . 4780 sq. cm (741 sq. in.)	
Separator:	Type . . . . . straw walkers	
	Width . . . . . 1391 mm (55 in.)	
Cleaning Shoe:	Chaffer width . . . . . 1286 mm (51 in.)	
	Chaffer length . . . . . 830 mm (32-1/2 in.)	
	Sieve width . . . . . 1286 mm (51 in.)	
	Sieve length . . . . . 1159 mm (46 in.)	
	Precleaner width . . . . . 1286 mm (51 in.)	
	Precleaner length . . . . . 840 mm (33 in.)	
	Total area . . . . . 411 sq. cm (6370 sq. in.)	
Straw Walkers:	Type . . . . . Lip	
	Number of walkers . . . . . 4	
	Length . . . . . 4500 mm (177 in.)	
	Total area . . . . . 626 sq. cm (9702 sq. in.)	
Grain Tank:	Capacity . . . . . 7.0 cu m (204 bu.)	
	Average unloading rate . . . . . 4200L/min. (120 bu./min.)	
Weights:	Less Header (Base equipment on Corn Combine) . . . . . 10935 kg (24,110 lb.)	
Capacities:	Fuel tank . . . . . 530L (140 gal.)	
	Cooling system (with heater) . . . . . 36L (38 U.S. qts.)	
	Engine crankcase (with filter) . . . . . 23.2L (24-1/2 U.S. qts.)	
	Transmission . . . . . 9.6L (10 U.S. qts.)	
	Final Drives (each) . . . . . 8.0L (8.5 U.S. qts.)	
	Feeder House Reverser Gearcase . . . . . 1.9L (2 U.S. pts.)	
	Separator Drive Gearcase . . . . . 2.4L (2-1/2 U.S. qts.)	
	Straw Walker Drive Gearcase . . . . . 0.7L (1-1/2 U.S. pts.)	
	Dual-Range Cylinder Drive Gearcase . . . . . 1.9L (2 U.S. qts.)	
	Engine Gearcase . . . . . 16L (17 U.S. qts.)	
	Loading Auger Gearcase . . . . . 4.7L (5 U.S. qts.)	
	Hydraulic/Hydrostatic Reservoir . . . . . 34L (36 U.S. qts.)	

HX,1401,1015,F -19-13SEP94

*Specifications/Operating Speeds—9500 Combines*

**OPERATING SPEEDS—9500 COMBINES**

Speeds shown are average and can vary from machine to machine. Speeds are rated at high idle with separator engaged, no load.

Engine:	Slow Idle (Separator Off) . . . . .	1200 rpm
	Mid Speed . . . . .	1650 rpm
	Fast Idle (Separator Engaged) . . . . .	2340 rpm
	Separator Full Load . . . . .	2200 rpm
Separator Drive Shaft Speed . . . . .		1550 rpm
Main Countershaft Speed . . . . .		1550 rpm
Hydrostatic Pump Speed:	Ring and Pinion Final Drives . . . . .	3510 rpm
Cylinder Speed:	High Range . . . . .	480-980 rpm
	Low Range . . . . .	240-480 rpm
	Grain Special . . . . .	470-960 rpm
	Edible Bean . . . . .	150-250 rpm
Feeder House Lower Shaft:	Fixed Speed . . . . .	520 rpm
	Variable . . . . .	520-715 rpm
Secondary Countershaft . . . . .		530 rpm
Cleaning Fan:	Standard . . . . .	750-1350 rpm
	Optional . . . . .	500-980 rpm
Clean Grain Elevator . . . . .		400 rpm
Tailings Elevator . . . . .		430 rpm
Shoe Crankshaft . . . . .		280 rpm
Straw Walkers . . . . .		170 rpm
Unloading Auger Countershaft . . . . .		1060 rpm
Loading Auger . . . . .		460 rpm
Inner Grain Tank Unloading Augers:	Front . . . . .	360 rpm
	Rear . . . . .	360 rpm
Vertical and Horizontal Unloading Augers . . . . .		390 rpm
Straw Chopper:	Low (Corn) . . . . .	1595 rpm
	High (Grain) . . . . .	2130 rpm
Straw Spreader Shaft . . . . .		235 rpm
Shoe Grain Supply Augers Shaft . . . . .		405 rpm

HX,1401,1015,G -19-13SEP94

10  
15  
7