

Product: John Deere 2500, 2500A, and 2500E Professional Greens Mower Service Repair Technical Manual
Full Download: <https://www.bobmanualstore.com/downloads/john-deere-2500-2500a-and-2500e-professional-greens-mower-service-repair-technical-manual/>

JOHN DEERE
WORLDWIDE COMMERCIAL & CONSUMER
EQUIPMENT DIVISION

Professional Greens Mower
2500, 2500A, and 2500E

TM1757 DEC05

TECHNICAL MANUAL



JOHN DEERE

North American Version
Litho in U.S.A.

Sample manual. Download All 820 pages at:

<https://www.bobmanualstore.com/downloads/john-deere-2500-2500a-and-2500e-professional-greens-mower-service-repair-technical-manual/>

Product: John Deere 2500, 2500A, and 2500E Professional Greens Mower Service Repair Technical Manual
Full Download: <https://www.bobmanualstore.com/downloads/john-deere-2500-2500a-and-2500e-professional-greens-mower-service-repair-technical-manual/>

Sample manual. Download All 820 pages at:

<https://www.bobmanualstore.com/downloads/john-deere-2500-2500a-and-2500e-professional-greens-mower-service-repair-technical-manual/>

INTRODUCTION

Manual Description

This technical manual is written for an experienced technician and contains sections that are specifically for this product. It is a part of a total product support program.

The manual is organized so that all the information on a particular system is kept together. The order of grouping is as follows:

- Table of Contents
- Specifications and Information
- Identification Numbers
- Tools and Materials
- Component Location
- Schematics and Harnesses
- Theory of Operation
- Operation and Diagnostics
- Diagnostics
- Tests and Adjustments
- Repair
- Other

NOTE: Depending on the particular section or system being covered, not all of the above groups may be used.

The bleed tabs for the pages of each section will align with the sections listed on this page. Page numbering is consecutive from the beginning of the Safety section through the last section.

We appreciate your input on this manual. If you find any errors or want to comment on the layout of the manual please contact us.

Safety

Specifications and Information

Gas Engine

Diesel Engine

Electrical

Power Train

Hydraulics

Steering

Brakes

Attachments

Miscellaneous

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 2005
Deere & Co.
John Deere Worldwide Commercial and
Consumer Equipment Division
All rights reserved
Previous Editions
COPYRIGHT© 2003, 2004, 2005

SAFETY

Recognize Safety Information



MIF

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.


Follow recommended precautions and safe servicing practices.

Understand Signal Words

A signal word - DANGER, WARNING, or CAUTION - is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.

Replace Safety Signs




MIF

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.

Handle Fluids Safely - Avoid Fires


Be Prepared For Emergencies



MIF

- When you work around fuel, do not smoke or work near heaters or other fire hazards.
- Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.
- Make sure machine is clean of trash, grease, and debris.
- Do not store oily rags; they can ignite and burn spontaneously.
- Be prepared if a fire starts.
- Keep a first aid kit and fire extinguisher handy.
- Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.

Use Care In Handling and Servicing Batteries



MIF

SAFETY

Prevent Battery Explosions

- Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.
- Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.
- Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).

Prevent Acid Burns

- Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid acid burns by:

1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.


If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 10 - 15 minutes.
4. Get medical attention immediately.

If acid is swallowed:

1. Drink large amounts of water or milk.
2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
3. Get medical attention immediately.

Wear Protective Clothing



MIF


Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.

Use Care Around High-Pressure Fluid Lines

Avoid High-Pressure Fluids



MIF

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid injury from escaping fluid under pressure by stopping the engine and relieving pressure in the system before disconnecting or connecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.

Avoid Heating Near Pressurized Fluid Lines




MIF

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.

SAFETY

Service Machines Safely



MIF


Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.

Use Proper Tools

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards. Use power tools only to loosen threaded parts and fasteners. For loosening and tightening hardware, use the correct size tools. Do not use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches. Use only service parts meeting John Deere specifications.

Park Machine Safely




MIF

Before working on the machine:

1. Lower all equipment to the ground.
2. Stop the engine and remove the key.
3. Disconnect the battery ground strap.
4. Hang a "Do Not Operate" tag in operator station.

Support Machine Properly and Use Proper Lifting Equipment



MIF

If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

Lifting heavy components incorrectly can cause severe injury or machine damage. Follow recommended procedure for removal and installation of components in the manual.

Work In Clean Area

Before starting a job:

1. Clean work area and machine.
2. Make sure you have all necessary tools to do your job.
3. Have the right parts on hand.
4. Read all instructions thoroughly; do not attempt shortcuts.

Using High Pressure Washers


Directing pressurized water at electronic/electrical components or connectors, bearings, hydraulic seals, fuel injection pumps or other sensitive parts and components may cause product malfunctions. Reduce pressure and spray at a 45 to 90 degree angle.

Illuminate Work Area Safely

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.

SAFETY

Work In Ventilated Area



MIF

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.

Warning: California Proposition 65 Warning

Gasoline engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Remove Paint Before Welding or Heating

Avoid potentially toxic fumes and dust. Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch. Do all work outside or in a well ventilated area. Dispose of paint and solvent properly. Remove paint before welding or heating: If you sand or grind paint, avoid breathing the dust. Wear an approved respirator. If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.


Avoid Harmful Asbestos Dust

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos. Keep bystanders away from the area.

Service Tires Safely



MIF

Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.


Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and not in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.

SAFETY


Avoid Injury From Rotating Blades, Augers and PTO Shafts



MIF

Keep hands and feet away while machine is running. Shut off power to service, lubricate or remove mower blades, augers or PTO shafts.

Service Cooling System Safely




MIF

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off machine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

Handle Chemical Products Safely



MIF

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques. Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

Dispose Of Waste Properly

Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries. Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them. Do not pour waste onto the ground, down a drain, or into any water source. Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.

Live With Safety



MIF

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.

SAFETY



SPECIFICATIONS AND INFORMATION TABLE OF CONTENTS

Table of Contents

Specifications	9
General Vehicle Specifications.....	9
Repair Information.....	12
Metric Fastener Torque Values	12
Metric Fastener Torque Values - Grade 7....	13
Inch Fastener Torque Values	14
O-Ring Seal Service Recommendations.....	15
Fuel	19
Using Proper Fuel	19
Oils & Lubricants	20
Engine Oil	20
Hydrostatic Transmission and Hydraulic Oil	20
Grease.....	21
Alternative Lubricants.....	21
Synthetic Lubricants	21
Lubricant Storage	21
Mixing of Lubricants	21
Oil Filters	22
Coolant Specifications	22
Engine Coolant.....	22
Engine Coolant Drain Interval	23
Identification Numbers.....	24
Machine Identification Number Locations	24
Operational Checkout	25
Interlock System Operation	25
General Information.....	26
Diesel Engine Air Filter Restriction Indicator Check	26
Hydraulic Reservoir Oil Level Check.....	26
Hydraulic Oil Filter Restriction Indicator Check	27
Start Circuit Check	28
Electronic Control Module Check	28

SPECIFICATIONS AND INFORMATION TABLE OF CONTENTS



SPECIFICATIONS AND INFORMATION SPECIFICATIONS

Specifications

General Vehicle Specifications

NOTE: Specifications and design subject to change without notice.

Gasoline Engine

Make.....	Kawasaki
Type.....	4 Cycle, V-Twin
Model.....	FD620D
Displacement.....	617 mL (37.7 cu in.)
Aspiration.....	Natural
Cooling System.....	Liquid cooled
Cooling System Capacity.....	3.5 L (3.7 qt)
Lubrication.....	Full pressure
Engine Oil Capacity (With Filter).....	1.9 L (2.0 qt)
Oil Filter.....	Replaceable, full flow
Valving.....	Overhead valves
Air Cleaner.....	Paper element with foam pre-cleaner
Bore.....	79 mm (3.11 in.)
Stroke.....	68 mm (2.68 in.)
Compression Ratio.....	9.0:1
Slow Idle.....	1550 ± 100 rpm
Fast Idle.....	3400 ± 50 rpm

Fuel System - Gasoline Engine

Fuel Tank Location.....	Behind operator seat
Fuel Tank Capacity.....	32.2 L (8.5 gal)
Fuel (Minimum Octane).....	Unleaded gasoline, 87 octane
Fuel Delivery.....	Electric fuel pump
Carburetor.....	Float-type, down draft
Fuel Filter.....	Replaceable element
Gasoline/Alcohol Blends.....	Up to 10% Ethyl Alcohol/90% Unleaded (by volume)
Gasoline/Ether Blends.....	Up to 15% MTBE/85% Unleaded (by volume)
Fuel Shutoff Solenoid.....	Below carburetor float bowl

SPECIFICATIONS AND INFORMATION SPECIFICATIONS

Diesel Engine

Make.....	Yanmar
Type.....	.4 Cycle, 3 cylinder, in-line
Model.....	3TNE68
Displacement.....	784 mL (47.8 cu in.)
Aspiration.....	Natural
Cooling System.....	Liquid cooled
Cooling System Capacity.....	3.5 L (3.7 qt)
Lubrication.....	Full pressure
Engine Oil Capacity (With Filter).....	2.2 L (2.3 qt)
Oil Filter.....	Replaceable, full flow
Valving.....	Overhead valves
Air Cleaner.....	Semi-cyclone, dry type duel stage
Bore.....	68 mm (2.68 in.)
Stroke.....	72 mm (2.83 in.)
Compression Ratio.....	23:1
Slow Idle.....	1450 ± 100 rpm
Fast Idle.....	3225 ± 50 rpm

Fuel System - Diesel Engine

Fuel Tank Location.....	Behind operator seat
Fuel Tank Capacity.....	32.2 L (8.5 gal)
Fuel (Above 4°C [40°F]).....	Grade No. 2-D
Fuel (Below 4°C [40°F]).....	Grade No. 1-D
Fuel (All Temperatures - Above 1500 M [5000 ft]).....	Grade No. 1-D
Fuel Centane (Minimum).....	45
Fuel Delivery.....	Mechanical fuel pump

Drive Train

Type.....	Hydrostatic
Drive Wheels.....	Front
Pump Drive.....	Flex coupler on engine flywheel-to-driven coupler on pump shaft
Travel Speed (Forward).....	0-12.9 km/h (0-8.0 mph)
Travel Speed (Forward - Mowing).....	0-6.4 km/h (0-4.0 mph)
Travel Speed (Reverse).....	0-7.1 km/h (0-4.4 mph)

Hydraulics

Hydraulic Reservoir Oil Capacity.....	20.4 L (5.4 gal)
Hydraulic System Oil Capacity.....	28.8 L (7.6 gal)
Pump Type - 2500, 2500A.....	Triple gear
Pump Type - 2500E.....	Double gear
Pump Drive.....	Driven coupler from hydrostatic pump shaft
Systems.....	Mow (reel drive), lift, and steering
Cutting Unit Lift.....	Front and rear cylinder
Oil Cooler.....	Standard - all except "E" model
Mow/Backlap Valve - 2500 and 2500A.....	Electro-hydraulic
Mow/Backlap Function - 2500E.....	Electrically controlled
Lift Control Valve.....	Electro-hydraulic

SPECIFICATIONS AND INFORMATION SPECIFICATIONS

Steering

Type Power, hydraulic, rear wheel

Brakes

Main Braking Hydrostatic (dynamic)

Park Brake Dual disc

Park Brake Actuation Pedal

Cutting Units

Number of Cutting Units 3

Cutting Unit Drive - 2500 and 2500A Direct hydraulic motors

Cutting Unit Drive - 2500E 48V Electric with controllers

Reel Diameter 12.7 cm (5 in.)

Number of Blades (Standard) 11

Number of Blades (Optional) 7

Clip Frequency @ 6.4 km/h (4.0 mph) 4.44 mm (0.175 in.)

Front Rollers Optional - smooth or grooved

Bed Knife Adjustment Bed knife-to-reel

Height-of-Cut¹ 2.4-22 mm (3/32-7/8 in.)

Tires

Smooth - Front and Rear 18 x 10.50-10, 2 Ply

Smooth - Front and Rear 20 x 10.00-10, 2 Ply

Soft Trac - Front and Rear 20 x 10.00-10, 4-Ply

Weights and Dimensions

Weight

Machine (Gasoline Powered) 576 kg (1270 lb)

Machine (Diesel Powered) 626 kg (1380 lb)

Overall Width

Without Cutting Reels 1294.9 mm (51 in.)

With Cutting Reels 1694.8 mm (66.7 in.)

With Optional Grass Catchers 1847.9 mm (72.75 in.)

Overall Length

Without Cutting Reels 2272 mm (89.5 in.)

With Cutting Reels 2272 mm (89.5 in.)

With Optional Grass Catchers 2630 mm (103.5 in.)

Overall Height 1940.3 mm (76.5 in.)

1. Minimum 2 mm (0.080 in.) with ultra low cut tournament bedknife.

SPECIFICATIONS AND INFORMATION REPAIR INFORMATION

Repair Information

Metric Fastener Torque Values

Property Class and Head Markings	4.8 	8.8 9.8 	10.9 	12.9
Property Class and Nut Markings	5 	10 	10 	12

MIF (TS1163)

SIZE	Class 4.8		Class 8.8 or 9.8				Class 10.9				Class 12.9					
	Lubricated ¹		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft
M6	4.8	3.5	6	4.5	9	6.5	11	8.5	13	9.5	17	12	15	11.5	19	14.5
M8	12	8.5	15	11	22	16	28	20	32	24	40	30	37	28	47	35
M10	23	17	29	21	43	32	55	40	63	47	80	60	75	55	95	70
M12	40	29	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	47	80	60	120	88	150	110	175	130	225	165	205	150	260	109
M16	100	73	125	92	190	140	240	175	275	200	350	225	320	240	400	300
M18	135	100	175	125	260	195	330	250	375	275	475	350	440	325	560	410
M20	190	140	240	180	375	275	475	350	530	400	675	500	625	460	800	580
M22	260	190	330	250	510	375	650	475	725	540	925	675	850	625	1075	800
M24	330	250	425	310	650	475	825	600	925	675	1150	850	1075	800	1350	1000
M27	490	360	625	450	950	700	1200	875	1350	1000	1700	1250	1600	1150	2000	1500
M30	675	490	850	625	1300	950	1650	1200	1850	1350	2300	1700	2150	1600	2700	2000
M33	900	675	1150	850	1750	1300	2200	1650	2500	1850	3150	2350	2900	2150	3700	2750
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2750	4750	3500

1. "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated (yellow dichromate - Specification JDS117) without any lubrication.

DO NOT use these hand torque values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only and include a ±10% variance factor. Check tightness of fasteners periodically. DO NOT use air powered wrenches.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same class. Make sure fastener threads are clean and that you properly start

thread engagement. This will prevent them from failing when tightening.

When bolt and nut combination fasteners are used, torque values should be applied to the NUT instead of the bolt head.

Tighten toothed or serrated-type lock nuts to the full torque value.

Reference: JDS-G200.









SPECIFICATIONS AND INFORMATION REPAIR INFORMATION

Metric Fastener Torque Values - Grade 7

Size	Steel or Gray Iron Torque		Aluminum Torque	
	N•m	lb-ft	N•m	lb-ft
M6	11	8	8	6
M8	24	18	19	14
M10	52	38	41	30
M12	88	65	70	52
M14	138	102	111	82
M16	224	165	179	132

SPECIFICATIONS AND INFORMATION REPAIR INFORMATION

Inch Fastener Torque Values

SAE Grade and Head Markings	1 or 2 ^a No Marks 	5 5.1 5.2 	8 8.2 
SAE Grade and Nut Markings	2 No Marks 	5  	8  

MIF (TS1162)

SIZE	Grade 1				Grade 2 ¹				Grade 5, 5.1 or 5.2				Grade 8 or 8.2			
	Lubricated ²		Dry ^b		Lubricated ^b		Dry ^b		Lubricated ^b		Dry ^b		Lubricated ^b		Dry ^b	
	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft
1/4	3.7	2.8	4.7	3.5	6	4.5	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.5	10	7	12	9	15	11	20	15	25	18	28	21	35	26
3/8	14	10	17	13	22	16	27	20	35	26	44	33	50	36	63	46
7/16	22	16	28	20	35	26	44	32	55	41	70	52	80	58	100	75
1/2	33	25	42	31	53	39	67	50	85	63	110	80	120	90	150	115
9/16	48	36	60	45	75	56	95	70	125	90	155	115	175	130	225	160
5/8	67	50	85	62	105	78	135	100	170	125	215	160	215	160	300	225
3/4	120	87	150	110	190	140	240	175	300	225	375	280	425	310	550	400
7/8	190	140	240	175	190	140	240	175	490	360	625	450	700	500	875	650
1	290	210	360	270	290	210	360	270	725	540	925	675	1050	750	1300	975
1-1/8	470	300	510	375	470	300	510	375	900	675	1150	850	1450	1075	1850	1350
1-1/4	570	425	725	530	570	425	725	530	1300	950	1650	1200	2050	1500	2600	1950
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2150	1550	2700	2000	3400	2550
1-1/2	1000	725	1250	925	990	725	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

1. "Grade 2" applies for hex cap screws (not hex bolts) up to 152 mm (6-in.) long. "Grade 1" applies for hex cap screws over 152 mm (6-in.) long, and for all other types of bolts and screws of any length.

2. "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated (yellow dichromate - Specification JDS117) without any lubrication.

DO NOT use these hand torque values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only and include a ±10% variance factor. Check tightness of fasteners periodically. DO NOT use air powered wrenches.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same grade. Make sure fastener threads are clean and that you properly start

thread engagement. This will prevent them from failing when tightening.

When bolt and nut combination fasteners are used, torque values should be applied to the NUT instead of the bolt head.


Tighten toothed or serrated-type lock nuts to the full torque value.

Reference: JDS-G200.

SPECIFICATIONS AND INFORMATION REPAIR INFORMATION

O-Ring Seal Service Recommendations

Face Seal Fittings with Inch Stud End Torques




MIF

NOTE: Torque tolerance is +15/-20%

Nominal Tube OD/Hose ID				Face Seal Tube/Hose End					O-Ring Stud Ends		
Metric Tube OD	Inch Tube OD			Thread Size	Tube Nut/ Swivel Nut Torque		Bulkhead Lock Nut Torque		Thread Size	Straight Fitting of Lock Nut Torque	
mm	Dash Size	in.	mm	in.	N•m	lb-ft	N•m	lb-ft	in.	N•m	lb-ft
	-3	0.188	4.76						3/8-24	8	6
6	-4	0.250	6.35	9/16-18	16	12	12	9	7/16-20	12	9
8	-5	0.312	7.94						1/2-20	16	12
10	-6	0.375	9.52	11/16-16	24	18	24	18	9/16-18	24	18
12	-8	0.500	12.70	13/16-16	50	37	46	34	3/4-16	46	34
16	-10	0.625	15.88	1-14	69	51	62	46	7/8-14	62	46
	-12	0.750	19.05	1-3/16-12	102	75	102	75	1-1/16-12	102	75
22	-14	0.875	22.22	1-3/16-12	102	75	102	75	1-3/16-12	122	90
25	-16	1.000	25.40	1-7/16-12	142	105	142	105	1-5/16	142	105
32	-20	1.25	31.75	1-11/16-12	190	140	190	140	1-5/8-12	190	140
38	-24	1.50	38.10	2-12	217	160	217	160	1-7/8-12	217	160

SPECIFICATIONS AND INFORMATION REPAIR INFORMATION

Face Seal Fittings with Metric Stud End Torques




MIF

NOTE: Torque tolerance is +15/-20%

Nominal Tube OD/Hose ID				Face Seal Tube/Hose End						O-Ring Stud Ends, Straight Fitting or Lock Nut					
Metric Tube OD	Inch Tube OD			Thread Size	Hex Size	Tube Nut/ Swivel Nut Torque		Bulkhead Lock Nut Torque		Thread Size	Hex Size	Steel or Gray Iron Torque		Aluminum Torque	
	mm	Dash Size	in.			mm	in.	mm	N•m			lb-ft	N•m	lb-ft	mm
6	-4	0.250	6.35	9/16-18	17	16	12	12	9	M12X1.5	17	21	15.5	9	6.6
8	-5	0.312	7.94												
										M14X1.5	19	33	24	15	11
10	-6	0.375	9.52	11/16-16	22	24	18	24	18	M16X1.5	22	41	30	18	13
12	-8	0.500	12.70	13/16-16	24	50	37	46	34	M18X1.5	24	50	37	21	15
16	-10	0.625	15.88	1-14	30	69	51	62	46	M22X1.5	27	69	51	28	21
	-12	0.750	19.05	1-3/16-12	36	102	75	102	75	M27X2	32	102	75	46	34
22	-14	0.875	22.22	1-3/16-12	36	102	75	102	75	M30X2	36				
25	-16	1.000	25.40	1-7/16-12	41	142	105	142	105	M33X2	41	158	116	71	52
28										M38X2	46	176	130	79	58
32	-20	1.25	31.75	1-11/16-12	50	190	140	190	140	M42X2	50	190	140	85	63
38	-24	1.50	38.10	2-12	60	217	160	217	160	M48X2	55	217	160	98	72

O-Ring Face Seal Fittings



MIF


1. Inspect the fitting sealing surfaces (A). They must be free of dirt or defects.
2. Inspect the O-ring (B). It must be free of damage or defects.
3. Lubricate O-rings and install into groove using petroleum jelly to hold in place.
4. Push O-ring into the groove with plenty of petroleum jelly so O-ring is not displaced during assembly.
5. Index angle fittings and tighten by hand-pressing joint together to ensure O-ring remains in place.

IMPORTANT: Avoid damage! DO NOT allow hoses or lines to twist when tightening fittings. Use two wrenches to tighten hose connections: one to hold the hose, and the other to tighten the swivel fitting.

6. Tighten fitting or nut to torque value shown on the chart per dash size stamped on the fitting. Do not allow hoses to twist when tightening fittings.


O-Ring Boss Fittings

1. Inspect O-ring boss seat. It must be free of dirt and defects. If repeated leaks occur, inspect for defects with a magnifying glass. Some raised defects can be removed with a slip stone.



MIF

2. Put hydraulic oil or petroleum jelly on the O-ring (B). Place electrical tape over the threads to protect O-ring from nicks. Slide O-ring over the tape and into the groove (A) of fitting. Remove tape.



MIF

3. For angle fittings (B), loosen special nut (A) and push special washer (C) against threads so O-ring can be installed into the groove of fitting.
4. Turn fitting into the boss by hand until special washer or washer face (straight fitting) contacts boss face and O-ring is squeezed into its seat.
5. To position angle fittings, turn the fitting counterclockwise a maximum of one turn.
6. Tighten straight fittings to torque value shown on chart. For angle fittings, tighten the special nut to value shown in the chart while holding body of fitting with a wrench.

SPECIFICATIONS AND INFORMATION REPAIR INFORMATION

Straight Fitting or Special Nut Torque

Thread Size	Torque ¹		Number of Flats ²
	N•m	lb-ft	
3/8-24 UNF	8	(6)	2
7/16-20 UNF	12	(9)	2
1/2-20 UNF	16	(12)	2
9/16-18 UNF	24	(18)	2
3/4-16 UNF	46	(34)	2
7/8-14 UNF	62	(46)	1-1/2
1-1/16-12 UN	102	(75)	1
1-3/16-12 UN	122	(90)	1
1-5/16-12 UN	142	(105)	3/4
1-5/8-12 UN	190	(140)	3/4
1-7/8-12 UN	217	(160)	1/2

1. Torque tolerance is ± 10 percent.

2. To be used if a torque wrench cannot be used. After tightening fitting by hand, put a mark on nut or boss; then tighten special nut or straight fitting the number of flats shown.

SPECIFICATIONS AND INFORMATION FUEL

Fuel

Using Proper Fuel

Using Proper Fuel (Diesel)

Use the proper diesel fuel to help prevent decreased engine performance and increased exhaust emissions. Failure to follow the fuel requirements listed below can void your engine warranty.

Contact your local fuel distributor for properties of the diesel fuel in your area.

In general, diesel fuels are blended to satisfy the low temperature requirements of the geographical area in which they are marketed.

Diesel fuels specified to EN 590 or ASTM D975 are recommended.

Required Fuel Properties

In all cases, the fuel shall meet the following properties:

Cetane number of 45 minimum. Cetane number greater than 50 is preferred, especially when temperatures are below -20°C (-4°F) or elevations above 1500 m (5000 ft).

Cold Filter Plugging Point (CFPP) below the expected low temperature OR **Cloud Point** at least 5°C (9°F) below the expected low temperature.

Fuel lubricity should pass a minimum load level of 3100 grams as measured by ASTM D6078 or maximum scar diameter of 0.45 mm as measured by ASTM D6079 or ISO 12156-1.

If a fuel of low or unknown lubricity is used, addition of John Deere PREMIUM DIESEL FUEL CONDITIONER at the specified concentration is recommended.

Sulfur Content

- Diesel fuel quality and fuel sulfur content must comply with all existing emissions regulations for the area in which the engine operates.
- Sulfur content less than 0.05% (500 ppm) is recommended for best performance.
- Diesel fuel sulfur content greater than 0.5% (5000 ppm) should not be used.

IMPORTANT: Avoid damage! Do not mix diesel engine oil or any other type of lubricating oil with diesel fuel.

Handling and Storing Diesel Fuel



CAUTION: Avoid injury! Handle fuel carefully. Do not fill the fuel tank when engine is running. Do not smoke while you fill the fuel tank or service the fuel system.

IMPORTANT: Avoid damage! Do not use galvanized containers—diesel fuel stored in galvanized containers reacts with zinc coating in the container to form zinc flakes. If fuel contains water, a zinc gel will also form. The gel and flakes will quickly plug fuel filters and damage fuel injectors and fuel pumps.

- Fill the fuel tank at the end of each day's operation to prevent water condensation and freezing during cold weather.

IMPORTANT: Avoid damage! The fuel tank is vented through the filler cap. If a new cap is required, always replace it with an original vented cap.

- When fuel is stored for an extended period or if there is a slow turnover of fuel, add a fuel conditioner to stabilize the fuel and to prevent water condensation. Contact your fuel supplier for recommendations.

Using Proper Fuel (Gas)

Use regular grade unleaded fuel with an octane rating of 87 octane or higher. Fuel blends containing up to 10% ethanol or up to 15% MTBE reformulated fuel are acceptable. Do not use fuel or additives containing methanol as engine damage can occur.

Always use fresh, clean fuel that is purchased in a quantity that can be used within approximately 30 days, or add fuel stabilizer.

Fuel is blended to give best seasonal performance. To avoid engine performance problems such as hard starting or vapor lock, use in-season fuel. Use fuel during warm weather that was purchased during that season, and use fuel during cold weather that was purchased during that season.

Fuel can become stale in machines with engines that are used seasonally or infrequently during a season. Stale fuel can produce varnish and plug carburetor or injector components which can affect engine performance.

Keep fuel storage container tightly covered and in a cool area out of direct sunlight. Fuel can break down and degrade if not sealed properly or exposed to sun and heat.

SPECIFICATIONS AND INFORMATION OILS & LUBRICANTS

Condensation may collect in the fuel tank because of a variety of operating or environmental conditions and, over time, may affect your machine's operation. Fill fuel tank at the end of daily use and store fuel in plastic containers to reduce condensation.


For best year-round performance and fuel-handling, add stabilizer to fuel immediately after fuel purchase. Such practice helps prevent engine performance problems and allows fuel storage in the machine all year without draining.

Oils & Lubricants

Engine Oil

Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following John Deere oils are preferred:




MX4888

- TURF-GARD™
- PLUS-4™

Other oils may be used if above John Deere oils are not available, provided they meet the following specification:

- API Service Classification SG or higher

Hydrostatic Transmission and Hydraulic Oil



M58275 (MIF)

Use the following oil viscosity based on the air temperature range. Operating outside of the recommended oil air temperature range may cause premature hydrostatic transmission failure.

IMPORTANT: Avoid damage! Only use a quality oil in this transmission. DO NOT use engine oil in this transmission. Do not mix any other oils in this transmission. Do not use "Type F" (Red) Automatic Transmission Fluid in this transmission.

The following oil is preferred:

- JD HY-GARD™

The following oil is allowed:

- Oils meeting John Deere Standard JDM J20C
- Bio HY-GARD¹

The following oil is not recommended:

- Biodegradable oils other than Bio HY-GARD

1. Bio HY-GARD may be used under normal cutting conditions. Do not use on machines used for vertical cutting in temperatures above 32°C (90°F) or scalping operations. Bio HY-GARD should be changed every 400 hours or annually. Biodegradable oils other than Bio HY-GARD are not recommended. See DTAC Solution 01-12-00-2 for more information.

SPECIFICATIONS AND INFORMATION OILS & LUBRICANTS

Grease

IMPORTANT: Avoid damage! Use recommended John Deere greases to avoid component failure and premature wear.

The recommended John Deere greases are effective within an average air temperature range of -29° to 135° C (-20° to 275° F).

If operating outside that temperature range, contact your Servicing dealer for a special-use grease.

The following greases are preferred (this may change for high-speed applications such as cutting units):

- John Deere Multi-Purpose SD Polyurea Grease
- John Deere Multi-Purpose HD Lithium Complex Grease

If not using any of the preferred greases, be sure to use a general all-purpose grease with an NLGI grade No. 2 rating.

Wet or high-speed conditions may require use of a special-use grease. Contact your Servicing dealer for information.

Chassis And Roller Water Resistant Grease

This grease is specially formulated to prevent corrosion and water washout when used in a wet environment.

The following water resistant greases are **PREFERRED**:

- Special Purpose HD Water Resistant Grease - TY24425.
- Multi-Purpose HD Lithium Complex Grease - TY24416.

Other greases may be used if they meet or exceed the following specifications:

- John Deere Standard JDM J13A2, NLGI Grade 2.

IMPORTANT: Avoid damage! ONLY use quality grease in this application. DO NOT mix any other greases in this application. DO NOT use any BIO-GREASE in this application.

Alternative Lubricants

Conditions in certain geographical areas outside the United States and Canada may require different lubricant recommendations than the ones printed in this technical manual or the operator's manual. Consult with your John Deere Dealer, or Sales Branch, to obtain the alternative lubricant recommendations.

IMPORTANT: Avoid damage! Use of alternative lubricants could cause reduced life of the component.

If alternative lubricants are to be used, it is recommended that the factory fill be thoroughly removed before switching to any alternative lubricant.

Synthetic Lubricants

Synthetic lubricants may be used in John Deere equipment if they meet the applicable performance requirements (industry classification and/or military specification) as shown in this manual.

The recommended air temperature limits and service or lubricant change intervals should be maintained as shown in the operator's manual.

Avoid mixing different brands, grades, or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements. Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance.

Lubricant Storage

All machines operate at top efficiency only when clean lubricants are used. Use clean storage containers to handle all lubricants. Store them in an area protected from dust, moisture, and other contamination. Store drums on their sides. Make sure all containers are properly marked as to their contents. Dispose of all old, used containers and their contents properly.

Mixing of Lubricants

In general, avoid mixing different brands or types of lubricants. Manufacturers blend additives in their lubricants to meet certain specifications and performance requirements. Mixing different lubricants can interfere with the proper functioning of these additives and lubricant properties which will downgrade their intended specified performance.

SPECIFICATIONS AND INFORMATION COOLANT SPECIFICATIONS

Oil Filters

IMPORTANT: Avoid damage! Filtration of oils is critical to proper lubrication performance. Always change filters regularly.

The following John Deere oil filters are PREFERRED:

- AUTOMOTIVE AND LIGHT TRUCK ENGINE OIL FILTERS.

Most John Deere filters contain pressure relief and anti-drainback valves for better engine protection.

Other oil filters may be used if above recommended John Deere oil filters are not available, provided they meet the following specification:

- ASTB Tested In Accordance with SAE J806.

Coolant Specifications

Engine Coolant

The engine cooling system when filled with a proper dilution mixture of anti-freeze and deionized or distilled water provides year-round protection against corrosion, cylinder or liner pitting, and winter freeze protection down to -37°C (-34°F).

The following John Deere coolant is PREFERRED:

- **COOL-GARD™ PRE-DILUTED SUMMER COOLANT (TY16036).**

This coolant satisfies specifications for “Automobile and Light Duty Engine Service” and is safe for use in John Deere Lawn and Grounds Care/Golf and Turf Division equipment, including aluminum block gasoline engines and cooling systems.

The above preferred pre-diluted anti-freeze provides:

- Adequate heat transfer
- Corrosion-resistant chemicals for the cooling system
- Compatibility with cooling system hose and seal material
- Protection during extreme cold and extreme hot weather operations
- Chemically pure water for better service life
- Compliance with ASTM D4656 (JDM H24C2) specifications

If above preferred pre-diluted coolant is not available, the following John Deere concentrate is recommended:

- **COOL-GARD™ CONCENTRATED SUMMER COOLANT CONCENTRATE™ (TY16034).**

If either of above recommended engine coolants are not available use any Automobile and Light Duty Engine Service ethylene glycol base coolant, meeting the following specification:

- ASTM D4985 (JDM H24A2).

Read container label completely before using and follow instructions as stated.

SPECIFICATIONS AND INFORMATION COOLANT SPECIFICATIONS

IMPORTANT: Avoid damage! To prevent engine damage, DO NOT use pure anti-freeze or less than a 50% anti-freeze mixture in the cooling system. DO NOT mix or add any additives/conditioners to the cooling system in Lawn and Grounds Care/Golf and Turf Division equipment. Water used to dilute engine coolant concentrate must be of high quality - clean, clear, potable water (low in chloride and hardness - see table below) is generally acceptable. DO NOT use salt water. Deionized or distilled water is ideal to use. Coolant that is not mixed to these specified levels and water purity can cause excessive scale, sludge deposits, and increased corrosion potential.

Property	Requirements
Total Solids, Maximum	340 ppm (20 grns/gal)
Total Hardness, Maximum	170 ppm (10 grns/gal)
Chloride (as Cl), Maximum	40 ppm (2.5 grns/gal)
Sulfate (as SO ₄), Maximum	100 ppm (5.8 grns/gal)

Mix 50 percent anti-freeze concentrate with 50 percent distilled or deionized water. This mixture and the pre-diluted mixture (TY16036) will protect the cooling system down to -37°C (-34°F) and up to 108°C (226°F).

Certain geographical areas may require lower air temperature protection. See the label on your anti-freeze container or consult your John Deere dealer to obtain the latest information and recommendations.

Engine Coolant Drain Interval

When using John Deere Pre-Diluted (TY16036) Automobile and Light Duty Engine Service coolants, drain and flush the cooling system and refill with fresh coolant mixture every 36 months or 3,000 hours of operation, whichever comes first.

When using John Deere Concentrate (TY16034) Automobile and Light Duty Engine Service coolants, drain and flush the cooling system and refill with fresh coolant mixture every 24 months or 2,000 hours of operation, whichever comes first.

If above John Deere Automobile and Light Duty Engine Service coolants are not being used; drain, flush, and refill the cooling system according to instructions found on product container or in equipment operator's manual or technical manual.

SPECIFICATIONS AND INFORMATION IDENTIFICATION NUMBERS


Identification Numbers

Machine Identification Number Locations

When ordering parts or submitting a warranty claim, it is **IMPORTANT** that the machine product identification number and component serial number are included.


The location of the machine identification number and component serial numbers are shown.

Machine Identification Number




M84560

Gasoline Engine Serial Number




M84561

Diesel Engine Serial Number




M84562

Hydrostatic Pump Serial Number



M84786

Cutting Unit Serial Number




M84563

Operational Checkout


Interlock System Operation

It is important to understand the interlock system and how it works. Before performing the checkout procedures, become familiar with the interlock system so that an interlock function will not be mistaken for a machine problem.



For the starting motor to engage and the engine to run, the following conditions must be met simultaneously:

- Operator on seat and/or park brake engaged.
- Mow/transport lever/pedals in the TRANSPORT position.
- Mow/backlap valve in MOW position.



For the engine to run, the following condition must be met:

- Operator must be on the seat or the park brake must be engaged.

If the mow/transport lever is in the TRANSPORT position with the park brake not engaged and the operator rises off the seat, the engine will stop.

If the mow/transport lever is in the MOW position with the park brake engaged and the operator rises off the seat, the engine will stop.

If the operator is mowing and rises off the seat, the cutting reels and engine will stop.

In order to mow, the following conditions must be met:

- Operator in the operator seat.
- Throttle lever moved to the FAST position.
- Mow/transport lever in the MOW position.
- Cutting units lowered to the ground.
- Parking brake not engaged.
- Backlap valve not engaged.

If the operator is mowing and the park brake is depressed, the cutting reels will stop rotating.

If the operator is mowing and engages the backlapping valve while on the operator seat, the cutting reels will stop rotating.

If the operator attempts to backlap the cutting units with the operator seat occupied, the cutting reels will not rotate.

SPECIFICATIONS AND INFORMATION OPERATIONAL CHECKOUT

Product: John Deere 2500, 2500A, and 2500E Professional Greens Mower Service Repair Technical Manual

Full Download: <https://www.bobmanualstore.com/downloads/john-deere-2500-2500a-and-2500e-professional-greens-mower-service-repair-technical-manual/>

If the operator is backlapping the cutting units with the operator seat not occupied and the park brake is disengaged, the engine will stop.

NOTE: Indicator will not provide an accurate indication if the housing is cracked or broken.

General Information

The procedures covered in this group are used to give a quick checkout of all the systems and components on the unit. These checkouts should be run to insure proper operation after any extended storage, when the unit comes in for service and after repairs have been made on the unit. They can also be helpful in determining the value of the unit at trade-in time. The unit should be placed on a level surface to run checkout. All checkouts should be done and all the steps of each checkout should be followed.

Checkout List

- Conditions - How the unit should be set up for the checkout.
- Procedure - The specific action to be done.
- Normal - What should happen, or be heard, or seen.
- If Not Normal - Where to go if other tests or adjustments are needed.

When performing the checkout, be sure to set your machine up to the test conditions listed and follow the sequence carefully. The "NORMAL" paragraph gives the result that should happen when performing the checkout. If the results are not normal, follow the instructions listed in the "IF NOT NORMAL" paragraph to determine the cause and repair the malfunction.


Diesel Engine Air Filter Restriction Indicator Check

Conditions

- Engine stopped.
- Machine parked on a level surface.
- Cutting units lowered to the ground.
- Mow/transport lever in "TRANSPORT" position.
- Key switch in "STOP" position.
- Park brake engaged.

Procedure

1. Raise cowl.
2. Inspect the housing for cracks or other damage.



M84632

3. Check the position of the plunger in the air filter restriction indicator (A).

Normal

- The housing should be free of cracks or other damage.
- The plunger should be in the green area of the indicator.

If Not Normal

- If the housing is cracked or damaged, replace the indicator. (See "Remove and Install Air Filter Restriction Indicator" on page 175.)
- If plunger is in the red area of the indicator, service the air cleaner filter elements. (See "Remove and Install Air Cleaner Assembly" on page 176.)

Hydraulic Reservoir Oil Level Check

Condition

- Engine stopped.
- Machine parked on a level surface.
- Cutting units lowered to the ground.
- Mow/transport lever in the "TRANSPORT" position.
- Key switch in the "STOP" position.
- Hydraulic oil cold.
- Park brake engaged.

Sample manual. Download All 820 pages at:

<https://www.bobmanualstore.com/downloads/john-deere-2500-2500a-and-2500e-professional-greens-mower-service-repair-technical-manual/>